

ISOPRO®

Thermal insulation units 80mm
DIN EN 1992-1-1





OUR MISSION: FORWARD CONSTRUCTING.

It is our mission not only to provide the very latest building technology, but to also be one crucial step ahead of the game at all times. That is why we are constantly undertaking pioneering work in all product areas. Our employees consistently put their extensive practical experience and creativity to use in the interests of our customers. In constant dialogue with our target groups on a partnership basis, we are already developing the products today that will be needed tomorrow. Our momentum continues to set new benchmarks in structural engineering – yesterday, today and tomorrow, too. This is what we mean by "forward constructing".

CONTENTS

04 ■ ISOPRO® Type overview

Thermal insulation units

10 ■ General information Building physics Design principles

26 ■ ISOPRO® IP and IPT

Units for cantilevered balconies

42 ■ ISOPRO® IP two-part

Units for cantilevered balconies with prefab slabs

46 ■ ISOPRO® IP Var.

Units for connection to a wall or a vertically offset slab

54 ■ ISOPRO® IP corner and IPT corner

Units for cantilevered corner balconies

62 ■ ISOPRO® IPQ and IPZQ, IPQS/IPTQS and IPQZ

Units for supported balconies

70 ■ ISOPRO® IPTQQ and IPTQQS

Units for supported balconies with lifting loads

76 ■ ISOPRO® IPTD

Units for continuous slabs

84 ■ ISOPRO® IPH and IPE

Units for horizontal loads and earthquake loads

92 ■ ISOPRO® IPTA, IPTF and IPO

Units for parapets, balustrades and corbels

104 ■ ISOPRO® IPTS

Units for projecting reinforced concrete beams and joists

108 ■ ISOPRO® IPTW

Units for cantilevered reinforced concrete walls

114 ■ ISOPRO® Z-ISO



Supplement as intermediate insulation without structural function

116 ■ Service & contact

We are always there for you.
We will be wherever you are.


TYPE OVERVIEW

CANTILEVERED STRUCTURES




ISOPRO® IP

- Transfer of negative moments as well as positive and negative shearing forces with version IP QX
- Version with concrete compression bearings
- P. 26





ISOPRO® IPT

- Transfer of negative moments and positive shearing forces
- Version with steel pressure rods
- P. 26




ISOPRO® IP TWO-PART

- Transfer of negative moments and positive shearing forces
- Version with concrete compression bearings
- Two-part version for prefab slabs
- P. 46





ISOPRO® IP CORNER, IPT CORNER

- Transfer of negative moments and positive shearing forces
- Version IP with concrete compression bearings
- Version IPT with steel pressure rods
- Solution for corner balconies
- P. 54




TYPE OVERVIEW

CANTILEVERED STRUCTURES AT WALL CONNECTIONS/VERTICALLY OFFSET CEILINGS




ISOPRO® IP VAR. I

- Transfer of negative moments and positive shearing forces
- Version with concrete compression bearings
- Connection to a wall leading downwards
- P. 46




ISOPRO® IP VAR. II

- Transfer of negative moments and positive shearing forces
- Version with concrete compression bearings
- Connection to a wall leading upwards
- P. 46



ISOPRO® IP VAR. III UV

- Transfer of negative moments and positive shearing forces
- Version with concrete compression bearings
- Connection to a ceiling vertically offset downwards
- P. 46





ISOPRO® IP VAR. III HV

- Transfer of negative moments and positive shearing forces
- Version with concrete compression bearings
- Connection to a ceiling vertically offset upwards
- P. 46



TYPE OVERVIEW

SUPPORTED STRUCTURES





ISOPRO® IPQ

- Transfer of positive shearing forces
- Version with concrete compression bearings
- P. 62




ISOPRO® IPZO

- Transfer of positive shearing forces
- Version without compression bearing for constraint-free connections
- P. 62



ISOPRO® IPTQS

- Transfer of positive shearing forces
- IPTQS version with concrete compression bearings
- IPTQS version with steel pressure rods
- Short unit for bearing loads at specific points
- P. 62





ISOPRO® IPQZ

- Transfer of positive shearing forces
- Version without compression bearing for constraint-free connections
- Short unit for bearing loads at specific points
- P. 62



TYPE OVERVIEW

SUPPORTED STRUCTURES WITH LIFTING LOADS



ISOPRO® IPTQQ



- Transfer of negative and positive shearing forces
- Version with steel pressure rods
- P. 70



ISOPRO® IPTQQS



- Transfer of negative and positive shearing forces
- Version with steel pressure rods
- Short unit for bearing loads at specific points
- P. 70

HORIZONTAL LOADS AND EARTHQUAKE LOADS



ISOPRO® IPH

- Transfer of horizontal loads parallel and/or perpendicular to the insulation plane
- P. 84





ISOPRO® IPE

- Transfer of horizontal loads parallel and perpendicular to the insulation plane
- In combination with the ISOPRO® units IP, IPT and IPTD: Transfer of positive moments
- Used for earthquake
- P. 88

TYPE OVERVIEW



CONTINUOUS SLABS



ISOPRO® IPTD

- Transfer of positive and negative moments and shearing forces
- Version with tension/pressure rods
- P. 76



PARAPETS AND BALUSTRADES CONNECTED TO THE HORIZONTAL FACE



ISOPRO® IPTA

- Transfer of moments, normal forces and horizontal forces
- Used at specific points
- P. 92



BALUSTRADE CONNECTED TO THE VERTICAL FACE



ISOPRO® IPTF

- Transfer of moments, shearing forces and horizontal forces
- Used at specific points
- P. 96

CORBEL





ISOPRO® IPO

- Transfer of shearing forces and horizontal forces
- Used at specific points
- P. 100

TYPE OVERVIEW



BEAMS



ISOPRO® IPTS

- Transfer of negative moments and positive shearing forces
- Version with pressure rods
- P. 104



WALLS



ISOPRO® IPTW

- Transfer of negative moments, positive shearing forces and horizontal forces
- Version with pressure rods
- P. 108

INTERMEDIATE INSULATION



ISOPRO® Z-ISO

- No structural function
- Intermediate insulation for support at specific points
- P. 114

PRODUCT INFORMATION

FUNCTION OF THE ISOPRO® UNIT

As a load-bearing thermal insulation unit, ISOPRO® undertakes the following functions:

- Thermal separation of reinforced concrete components to resolve structural problems at the transition between internal and external components
- Frictional connection of the reinforced concrete components across the insulating joint.

The load transfer across the joint is carried out by means of tension and shear rods as well as a pressure component. Depending on the ISOPRO® type, the pressure component is designed as a pressure unit made of special concrete (IP unit) or as a steel pressure rod (IPT unit). For corrosion-protection reasons, and to reduce heat transition through the structural components, stainless steel reinforcement units are implemented in the area of the insulating body. The transition from stainless steel to carbon steel is carried out using a special welding method. In the area of the insulating body the tension rods of standard units are made of stainless steel and have a reduced diameter compared to the adjoining carbon steel rods.

The ISOPRO® unit is available in different load-bearing capacities. With regard to the load-bearing capacities, the units vary in terms of the number of tension and shear rods, as well as the number of pressure components. In principle, the units are available in heights from 160 mm. However, depending on the diameter of the shear rod used, there may be restrictions in terms of the minimum height.

During installation it is crucial to note the direction of installation indicated on the label. The direction of installation is marked clearly on each unit by the indication of the top and an arrow to the balcony side (of the cold area).

MATERIALS OF THE ISOPRO® UNIT

Tension, shear, pressure rod:	Reinforcing steel B500B Stainless steel rebar according to general technical approval Material no. 1.4571, 1.4362 or 1.4482
Compression bearing:	High-performance special concrete
Insulating body:	NEOPOR®* Rigid polystyrene foam, $\lambda = 0.031$ W/mK
Fireproof panels:	Fibre-cement panels of building material class A1 Intumescent coating

GENERAL TECHNICAL APPROVALS

ISOPRO®:	Z-15.7-243 and Z-15.7-244, DIBt Berlin
----------	--

MATERIALS OF THE ADJOINING PARTS

Concrete:	Standard concrete acc. to DIN 1045-1 or DIN EN 206-1 with a raw density of 2000 to 2600 kg/m ³
Concrete strength classes:	External components \geq C25/30 Internal components \geq C20/25
Reinforcing steel:	B500B


SUPPLEMENTARY REINFORCEMENT

The components adjoining the ISOPRO® units are reinforced in accordance with the structural engineer's design based on the structurally required reinforcement.


*Neopor® is a registered trademark of BASF, Ludwigshafen

PRODUCT COMPONENTS

ISOPRO® IP



ISOPRO® IPT



Our Applications Technology department would be pleased to assist in finding further solutions.

Phone: +49 (0) 7742 9215-300

Fax: +49 (0) 7742 9215-319

E-mail: technik@h-bau.de

CONCRETE COVERING

EXPOSURE CLASS AND CONCRETE COVERING

The minimum concrete strength for the components adjoining the ISOPRO® units as well as the required concrete covering c_v for the ISOPRO® units are calculated according to the exposure class and the approval. The higher minimum concrete strength class is definitive in each case.

Reinforcement corrosion		Minimum concrete strength class			Concrete covering [mm]	
DIN EN 1992-1-1		DIN EN 1992-1-1/NA	Approval for internal components	Approval for external components	Components c_{nom}	ISOPRO® c_v
XC3	Moderate humidity, external components, wet areas	C20/25	C20/25	C25/30	35	30
XC4	Alternately wet and dry, external components directly exposed to rain	C25/30			40	35
XD1	Moderate humidity, spray zone from road surfaces	C30/37			55	50
XS1	Salty air, external components near coast	C30/37			55	50
XD1	Moderate humidity, spray zone from road surfaces	C30/37			55	50
XS1	Salty air, external components near coast	C30/37			55	50

ISOPRO® CONCRETE COVERING

- In accordance with DIN EN 1992-1-1/NA, the c_v dimension of the ISOPRO® units may be reduced by $\Delta c_{dev} = 5$ mm using suitable quality measures during production.
- For ISOPRO® types IP/IPT two-part/IPT/IP Var., c_v35 or c_v50 can be selected for the tension rod concrete covering.
- The ISOPRO® IP corner unit is available with the concrete covering of c_v35/c_v50 for the tension rods.
- For the shear units, the concrete covering at the top is c_v35 to c_v85 , depending on the height.
- The concrete covering for pressure rods and shear rods at the bottom is generally c_v30 (usually lower exposure compared to the top side of the balcony).
- ISOPRO® IPTD units have a bottom concrete covering of c_v30 for the selected top concrete covering of c_v35 , and a bottom concrete covering of c_v50 for the selected top concrete covering of c_v50 .

DESIGN AND INSTALLATION

NOTES ON DESIGN

- The design for the reinforced concrete components adjoining the ISOPRO® units is provided by the structural engineer.
- When there are different concrete qualities in the adjoining components (e.g. balcony C25/30; ceiling C20/25), the lower concrete quality is definitive for designing ISOPRO® units.
- The specified table values for supplementary reinforcement apply to full utilisation of the ISOPRO® units. A reduction by m_{Ed}/m_{Rd} or v_{Ed}/v_{Rd} is permissible.
- The specified minimum heights depending on the shearing force load-bearing capacity apply to concrete cover cv35. The minimum heights must be increased by 20 mm accordingly for cv50.
- To bear planned horizontal loads, the ISOPRO® IP and IPT units must be combined with ISOPRO® IPH and IPE short units.
- ISOPRO® units for cantilevered constructions without live load, but with an ordinary moment from a load not increasing the shear forces, must be proven separately by our application technology
- For reinforcement, please note ability for concrete pouring. This applies in particular to ISOPRO® units with a high number of rods.

SPECIAL UNITS

- Beyond the standard units listed in this documentation, we also offer special structures tailored to the construction project, resultant forces and component geometry. Planning, design and production of special structures is carried out in compliance with the requirements of the approvals and according to DIN EN 1992-1-1 and DIN EN 1992-1-1/NA.

HANDLING AND INSTALLATION ON SITE


- When using ISOPRO® units with concrete compression bearings, please ensure that the frictional connection between the compression bearing and the concrete of the component is guaranteed. When using prefab slabs, an in-situ concrete or grouting strip at least 100 mm wide must be taken into account.
- For simultaneous use of ISOPRO® units with steel pressure rods and prefab slabs, it must be ensured that the width of the in-situ concrete strip is matched to the length of the pressure rods.
- When using ISOPRO® units with fire protection version R90/REI120, please ensure that the fireproof panels are not damaged.
- Please note that subsequent bending of the reinforcement rods on site will render the approval and warranty by H-BAU Technik GmbH void.
- On site partition of ISOPRO® metre units is possible – reduced load-bearing capacity and minimal edge distance of the ISOPRO® components must be taken into consideration.
- In highly reinforced structures (e.g. joists) it should be considered to install the ISOPRO® unit before the supplementary reinforcement.

DESIGN


DESIGN OF ISOPRO® UNITS – FEM CALCULATION/MANUAL CALCULATION

SYSTEM CALCULATION

Cantilevered balcony





Model



System

Supported balcony



SUPPORT CONDITIONS

Manual calculation: Clamped

Hinged

FEM calculation:

Torsion spring: 10,000 kNm/rad/m

Torsion spring: –

Vertical spring: 250,000 kN/m/m

Vertical spring: 250,000 kN/m/m

LOAD ASSUMPTIONS

g_k : Permanent loads (dead load + superimposed load)

q_k : Live load

G_k : Edge load (railings, balustrade, plinth, etc.)

M_k : Edge moment (due to horizontal load on railings, balustrade, etc.)

METHOD FOR FEM CALCULATION

- Calculate the balcony slab as a separate system from the load-bearing structure of the building
- Define supports in the connecting area with the aforementioned rigidities
- Calculate resultant forces using linear-elastic approach
- Select ISOPRO® units
- Set the calculated resultant forces as the edge load for the load-bearing structure of the building

NOTE

If the rigidity ratios along the slab edge vary significantly (e.g. supports along the slab edge and no continuous wall), the balcony slab should not be calculated as a system separate from the building. In this case, a hinged line should be defined along the edge of the balcony slab, with the aforementioned rigidities. The ISOPRO® units can be determined based on the joint forces.


SOFTWARE

DESIGN OF ISOPRO® UNITS – SOFTWARE ISOPRO® DESIGN

The ISOPRO® DESIGN program allows us to pass on to you our many years of experience in designing our ISOPRO® thermal insulation units for the most common balcony systems.

You can choose between different balcony systems comprising a cantilevered balcony, balcony on supports, loggia, internal corner balcony and external corner balcony or you can work with the free input tool when design values are known. After entering the geometric data and the applied loads, you can select the corresponding ISOPRO® units.

The arrangement and geometric parameters of the ISOPRO® units can be checked for feasibility in the layout and cross-section and, if necessary, can be printed out as a formwork drawing or exported as a DXF file for further editing.



ADVANTAGES

- All common balcony systems can be selected
- Design with FEM-module
- Log output including proof
- CAD export

Our Applications Technology department would be pleased to assist in finding further solutions.

Phone: +49 (0) 7742 9215-300

Fax: +49 (0) 7742 9215-319

E-mail: technik@h-bau.de

PROOF OF SERVICABILITY

CAMBERS AND BENDING SLENDERNESS

CAMBERS

A cantilevered slab deforms under load, with the maximum deflection occurring at the end of the cantilever arm. If a cantilevered slab is connected to an ISOPRO® unit, the share of deflection from the slab itself must be superimposed with that of the ISOPRO® unit in order to calculate the maximum deflection.

The ISOPRO® tension and pressure components behave in approximately the same way as a spring system that is stretched or compressed. The resulting angle of rotation α is used to calculate the maximum deflection by the ISOPRO® unit.

We recommend providing proof of the limit state of serviceability for the quasi-permanent load case combination. To calculate the required camber of the cantilevered slab, the deflection should be rounded up or down according to the direction of the planned drainage.


For the calculation of the deflection of the ISOPRO® units please refer to product chapters.

w_1 = deflection due to thermal insulation unit
 w_2 = deflection due to slab



BENDING SLENDERNESS

The bending slenderness is defined as the ratio of the static height d of the balcony slab to the cantilever length l_k . The bending slenderness of a slab has an impact on its vibration characteristics. We therefore recommend limiting the bending slenderness. Limits for the bending slenderness are specified on page 35.




ISOPRO® IP – Static system

DISTANCE BETWEEN EXPANSION JOINTS



DISTANCE BETWEEN EXPANSION JOINTS

Due to the influence of temperature on external components such as balconies or canopies, deflection of reinforced concrete components can occur. These components expand when heated and contract when cooled. If the reinforced concrete components are thermally separated with ISOPRO® units, then deflection of the ISOPRO® components parallel to the insulating joint occurs due to the deflection of the reinforced concrete slab.



Balcony slab under influence of temperature

To limit the stress on ISOPRO® units as a result of the influence of temperature, very long reinforced concrete components must be separated using expansion joints. The maximum permissible distance between expansion joints e is regulated in the technical approval. The maximum permissible distance between expansion joints e is dependent on the rod diameter and therefore on the ISOPRO® types used. Details can be found in the respective product sections. The use of fixed points such as corner supports or the use of ISOPRO® IPH or IPE units results in increased constraints, which means the maximum permissible distance between expansion joints must be reduced to $e/2$. To prevent uneven settlement of the structural components separated by expansion joints, we recommend connecting the slabs with longitudinally displaceable shear dowels type HED.



Expansion joint layout for different balcony systems

THERMAL INSULATION

THERMAL BRIDGES

Thermal bridges are weak points in the heat-conducting building envelope, which result in a locally increased heat loss in comparison with standard components. We distinguish between thermal bridges caused by geometric factors, where there is a larger external surface opposite the thermal outflow of the internal surface, and thermal bridges caused by material factors, where an increased heat loss occurs due to local installation parts or material changeovers.

IMPACT OF THERMAL BRIDGES

Thermal bridges have a significantly higher heat flow in comparison with the rest of the envelope surface. This increased heat flow causes the inside surface temperature to fall sharply in this area. The consequence is an increased heating energy requirement.

In particular when the outside temperature is low, the surface temperature can fall below what is referred to as the mould temperature. This leads to the formation of mould and the resulting health burdens.


If a further drop in the surface temperature causes the temperature to fall below the dew point temperature, the humidity in the room air condenses, which causes condensation to form on the cold surfaces concerned.

THE BALCONY THERMAL BRIDGE


A balcony designed as a projecting reinforced concrete slab is the classic example of a linear thermal bridge.

If a highly heat-conductive reinforced concrete slab penetrates the thermal insulation layer of the building, the effects of the thermal bridges – caused by geometric factors – are superimposed by the large external surface and the effects of the material-dependent thermal bridge. The results are a significant cooling of the ceiling in the rooms and, as a result, increased heating costs, condensation and mould formation.

If ISOPRO® thermal insulation units are used in the connecting area between the reinforced concrete slabs and the building, thermal bridges are minimised.



Temperature distribution in balcony with continuous reinforced concrete slab



Temperature distribution in balcony with thermally separated reinforced concrete slab

THERMAL INSULATION

THERMAL INSULATION CERTIFICATE – THERMAL BRIDGES IN ACCORDANCE WITH EnEV

For the energy performance certificate according to the German Energy Saving Regulation EnEV, all losses caused by thermal bridges must be accounted for. There are three methods of recording the calculations.

If there is no documentation of thermal bridges or if their design does not comply with the construction examples in accordance with DIN 4108 supplementary sheet 2:2006-03, a penalty surcharge on the mean U-value of the entire building of $\Delta U_{WB} = 0.10 \text{ W/(m}^2\text{K)}$ must be taken into consideration. Further documentation is not necessary.

The thermal bridge surcharge may be reduced to $\Delta U_{WB} = 0.05 \text{ W/(m}^2\text{K)}$ if all thermal bridges in the building are implemented in compliance with DIN 4108 supplementary sheet 2:2006-03. Conformity of balcony insulation units with DIN 4108 supplementary sheet 2:2006-03 fig. 70 is regulated in the general technical approval. In accordance with approvals Z-15.7-243 and Z-15.7-244, ISOPRO® units meet the requirements according to DIN 4108 supplementary sheet 2:2006-03, which enables use of the reduced thermal bridge surcharge $\Delta U_{WB} = 0.05 \text{ W/(m}^2\text{K)}$.

Another option for consideration of thermal bridges is providing detailed evidence of each individual thermal bridge present in the building, in accordance with DIN V 4108-6:2003-06. In this case, the thermal bridge coefficients of loss ψ for linear thermal bridges and χ for thermal bridges at specific points as well as the temperature factors $f_{RSi} \geq 0.7$ must be calculated for all thermal bridges in a building.

OVERVIEW OF THE METHODS ACCORDING TO EnEV

	Method 1	Method 2	Method 3
Description	The thermal bridges of the building are not documented individually and do not comply with the design according to DIN 4108 supplementary sheet 2	The thermal bridges of the building are designed in compliance with DIN 4108 supplementary sheet 2	The thermal bridges have been calculated in detail and documented according to DIN V 4108-6:2003-06 in connection with other recognised rules of technology (DIN EN ISO 10211)
Proof	No further proof	Regulated in the approvals for the balcony insulation units	Proven through detailed, three-dimensional thermal bridge calculation
Consideration	General: $\Delta U_{WB} = 0.10 \text{ W/(m}^2\text{K)}$	General: $\Delta U_{WB} = 0.05 \text{ W/(m}^2\text{K)}$	Detailed: $H_T = \sum U_i \cdot A_i \cdot F_{x,i} + \sum \psi_i \cdot l_i \cdot F_{x,i} + \sum \chi_i \cdot F_{x,i}$

NOTES

- It is not permissible to use a combination of the different methods.
- Object-related calculation of the ψ values on request.



Our Applications Technology department would be pleased to assist in finding further solutions.
 Phone: +49 (0) 7742 9215-300
 Fax: +49 (0) 7742 9215-319
 E-mail: technik@h-bau.de

FIRE PROTECTION



FIRE RESISTANCE CLASSES R90/REI120

Where there are fire protection requirements regarding the fire resistance class of components, all ISOPRO® units with concrete compression bearings are available in fire resistance class REI120 and all ISOPRO® units with a steel pressure plane are available in fire resistance class R90.

To this end, the ISOPRO® units are fitted with fireproof panels on the top and bottom ex works. The prerequisite for classification into R90/REI120 is that the adjoining components meet the requirements of the respective fire resistance class. If a physical barrier (E) and heat shielding (I) are also required in the event of fire, then it must be ensured that ISOPRO® Z-ISO FP1 in EI120 is used as the intermediate insulation where ISOPRO® units are used at specific points.



ISOPRO® unit with concrete compression bearings in REI120 version with fireproof panels at the top and bottom, intumescent coating at the side



ISOPRO® unit with steel pressure rods in R90 version with fireproof panels overhanging at the top and flush at the bottom

FIRE RESISTANCE CLASSES OF ISOPRO® UNITS

ISOPRO® units achieve the following fire resistance classes:

ISOPRO®	IP, IP two-part, IP corner, IP Var., IPQ, IPZQ, IPQS, IPQZ, IPH, IPE, IPO	IPT, IPT corner, IPTQS, IPTQQ, IPTQQS, IPTD, IPTA, IPTF, IPTS, IPTW	Z-ISO FP1
Fire resistance class	REI120	R90	EI120

FIRE PROTECTION

FIRE PROTECTION REGULATIONS FOR BALCONIES

According to DIN EN 13501-2:2010-02 (1a), balconies are considered to be load-bearing components without a separating function. Usually Building Codes do not place any specific requirements in terms of fire protection for balconies. As a result, the fire protection requirements must be checked in each individual case.

FIRE PROTECTION REGULATIONS FOR ACCESS BALCONIES

According to DIN EN 13501-2:2010-02 (1a), access balconies are considered to be load-bearing components without a separating function. To the extent that access balconies do not function as a "necessary corridor", the Model Building Regulation Section 31 does not set any specific requirements in terms of fire protection. Necessary corridors must be designed to be fireproof, highly fire resistant or fire resistant, depending on the building class. Whether or not the thermal insulation connection must be designed with a separating function must be checked in each individual case.

REQUIREMENTS OF ACCESS BALCONIES AS NECESSARY CORRIDORS:

Building class according to Model Building Regulation Section 2	Requirements of access balconies as necessary corridors		
	Model Building Regulation Section 31	DIN EN 13501-2	DIN 4102-2
1	Load-bearing and separating	N/A	N/A
2	Load-bearing and separating, fire-resistant	REI30	F30-B
3	Load-bearing and separating, fire-resistant	REI30	F30-AB (separating)
4	Load-bearing and separating, highly fire-resistant	REI60	F60-AB (separating)
5	Load-bearing and separating, fireproof	REI 90	R90-AB (separating)

NOTE

For fire protection requirements, please note that even a possible insulation layer between individual ISOPRO® units must also meet the fire protection requirements. This can be implemented with ISOPRO® Z-ISO FP1 in EI120.

FIRE BARRIERS


Fire barriers are required for buildings with a thermal insulation composite system made of EPS insulating materials with a thickness greater than 100 mm if there are more than three floors, in every second floor. This is achieved by the complete horizontal interruption of the insulation. Balconies, loggias and access balconies, which interrupt a ETICS completely horizontally, can take over the function of a fire barrier, so that can be dispensed with in this area on the additional execution of fire barriers. However, the fire barrier must connect laterally to the cantilever slabs, so that the fire protection interruption of the insulation is continuous. In the situation described ISOPRO® units in the fire protection versions REI120 or R90 must be used.

FIRE PROTECTION


FIRE RESISTANCE CLASS REI30

All ISOPRO® standard units can be classified in fire resistance class REI30 if the following requirements for the overall structure are met:

- The components adjoining the ISOPRO® unit are clad with mineral protective layers on the surface or
- The components adjoining the ISOPRO® unit are clad with protective layers made of non-combustible materials on the surface and
- The ISOPRO® unit is embedded in the overall structure with protection against exposure to direct flames from above and below.




REI30 formation in wall area




REI30 formation in door area

FIRE RESISTANCE CLASS REI120



REI120 embedment of ISOPRO® unit in thermal insulation composite system




REI120 embedment of ISOPRO® unit in non-combustible insulation


INSTALLATION INSTRUCTIONS

POSITION IN COMPONENT


To reliably prevent thermal bridges, the ISOPRO® units are installed in the insulation plane.




ISOPRO® IP – Installation cross-section for external thermal insulation composite system



ISOPRO® IP – Installation cross-section for single-leaf masonry




ISOPRO® IP – Installation cross-section for glass façade




ISOPRO® IP – Installation cross-section for double leaf masonry

DIRECTION OF INSTALLATION


During installation, note the correct direction of installation on the balcony/ceiling as well as at the top/bottom. Ensure that the tension rods are at the top and the compression bearings/pressure rods are at the bottom. Starting at the bottom on the balcony, the shear rod runs diagonally through the ISOPRO® unit and ends at the top of the ceiling.



ISOPRO® IP – Correct installation



ISOPRO® IP – Incorrect installation, tension rod must be at the top




ISOPRO® IP – Incorrect installation, shear rod must be on the bottom side of the balcony

INSTALLATION - PRESSURE JOINT

DIRECTION OF INSTALLATION


During installation it is crucial to note the direction of installation indicated on the label. The direction of installation is marked clearly on each unit by the indication of the top and an arrow to the balcony side (of the cold area).




ISOPRO® IP – correct installation

PRESSURE JOINT

Both when using prefabricated components and semi-finished components, i.e. also when installing ISOPRO® units in an in-situ concrete structure, ensure that a form-fitting connection is produced between the compression bearing and the fresh concrete. A pressure joint of $\geq 100\text{mm}$ must be provided for this purpose.



ISOPRO® IP – Pressure joint for in-situ concrete construction and vertically offset slabs



ISOPRO® IP – Pressure joint for prefab slabs on the ceiling





ISOPRO® IP and IPT

UNITS FOR CANTILEVERED CONCRETE COMPONENTS

ISOPRO® IP


- For transferring negative moments and positive and negative shearing forces
- Pressure plane with concrete compression bearings
- Load-bearing capacities IP 10 to IP 100
- Shearing force load-bearing capacities, standard, Q8, Q10, Q12, Q8X and Q10X
- Concrete covering of tension rods cv35 or cv50
- Unit heights depending on the shearing force load-bearing capacity starting from $h_{\min} = 160$ mm
- Fire resistance class REI120 available

ISOPRO® IPT

- Pressure plane with steel pressure rods
- Load-bearing capacities IPT 110 and IPT 150
- Shearing force load-bearing capacities Q10, Q12 and Q14
- Concrete covering of tension rods cv35 or cv50
- Unit heights depending on the shearing force load-bearing capacity starting from $h_{\min} = 160$ mm
- Fire resistance class R90 available

TYPE DESIGNATION


IP 65 Q8 cv35 h200 REI120




APPLICATION – UNIT ARRANGEMENT




This chapter provides planning aids and specific information about this product. In addition, the general information on materials, design, building physics, installation on site, etc. on pages 10 - 24 has also to be considered.




ISOPRO® IP/IPT – Cantilevered balconies




ISOPRO® IP/IPT – Cantilevered balconies in façade extensions




ISOPRO® IP/IPT – Cantilevered balconies in façade recesses




ISOPRO® IP/IPT in combination with IP QX and IPQS for internal corner balconies




ISOPRO® IP – Installation cross-section for external thermal insulation composite system



ISOPRO® IP – Installation cross-section for single-leaf masonry



ISOPRO® IP – Installation cross-section for glass façades



ISOPRO® IP – Installation cross-section for double leaf masonry

DESIGN TABLE FOR CONCRETE C 20/25

DESIGN VALUES OF ALLOWABLE MOMENTS m_{Rd} [kNm/m]

Unit height [mm] depending on c_v [mm]		ISOPRO®					
		Concrete \geq C20/25					
		IP 10	IP 15	IP 20	IP 25	IP 35	IP 45
35	50						
160	–	9,0	13,2	15,4	20,2	23,8	25,3
–	180	9,5	14,0	16,2	21,3	25,1	26,7
170	–	10,0	14,8	17,1	22,4	26,5	28,0
–	190	10,5	15,5	18,0	23,5	27,8	29,4
180	–	11,1	16,3	18,9	24,6	29,2	30,7
–	200	11,6	17,1	19,8	25,7	30,5	32,1
190	–	12,2	17,9	20,7	26,8	31,9	33,5
–	210	12,7	18,6	21,6	27,9	33,3	34,8
200	–	13,3	19,4	22,5	28,9	34,7	36,2
–	220	13,8	20,2	23,4	30,0	36,0	37,5
210	–	14,4	21,0	24,3	31,1	37,5	38,9
–	230	14,9	21,8	25,2	32,2	38,8	40,3
220	–	15,5	22,6	26,2	33,3	40,3	41,6
–	240	16,0	23,4	27,1	34,4	41,7	43,0
230	–	16,6	24,3	28,1	35,5	43,1	44,3
–	250	17,2	25,1	29,0	36,6	44,5	45,7
240	–	17,8	25,9	30,0	37,6	46,0	47,1
250	–	18,9	27,6	31,9	39,8	48,9	49,8

DESIGN VALUES OF ALLOWABLE SHEARING FORCES v_{Rd} [kN/m]

Capacity	h_{min} [mm]	IP 10	IP 15	IP 20	IP 25	IP 35	IP 45
Standard	160		34,8			43,5	
Q8	160			79,9			
Q10	170			124,9			
Q12	180			179,8			
Q8X	160			+53,3/-39,9			
Q10X	170			+83,3/-62,5			

DIMENSIONS AND ASSIGNMENT

ISOPRO®	IP 10	IP 15	IP 20	IP 25	IP 35	IP 45
Unit length [mm]	1.000					
Tension rods	4 \emptyset 8	6 \emptyset 8	7 \emptyset 8	10 \emptyset 8	11 \emptyset 8	13 \emptyset 8
Tension rods QX	5 \emptyset 8	7 \emptyset 8	8 \emptyset 8	12 \emptyset 8	13 \emptyset 8	15 \emptyset 8
Compression bearings	4			5		
Standard shear rods	4 \emptyset 6			5 \emptyset 6		
Shear rods Q8	6 \emptyset 8					
Shear rods Q10	6 \emptyset 10					
Shear rods Q12	6 \emptyset 12					
Shear rods Q8X	4 \emptyset 8/3 \emptyset 8					
Shear rods Q10X	4 \emptyset 10/3 \emptyset 10					

DESIGN TABLE FOR CONCRETE C 20/25

DESIGN VALUES OF ALLOWABLE MOMENTS m_{Rd} [kNm/m]

Unit height [mm] depending on c_v [mm]		ISOPRO®					
		Concrete \geq C20/25					\geq C30/37
		IP 50	IP 55	IP 65	IP 75	IP 90	IP 100
35	50						
160	–	30,1	35,0	35,0	–	–	–
–	180	31,7	36,9	36,9	–	–	–
170	–	33,4	38,8	38,8	44,4	44,0	57,1
–	190	35,1	40,7	40,7	46,6	46,1	60,0
180	–	36,8	42,6	42,6	48,7	48,3	63,0
–	200	38,5	44,6	44,6	50,9	50,5	65,9
190	–	40,1	46,5	46,5	53,1	52,7	68,9
–	210	41,8	48,4	48,4	55,3	54,8	71,8
200	–	43,4	50,3	50,3	57,4	57,0	74,7
–	220	45,0	52,2	52,2	59,6	59,2	77,6
210	–	46,7	54,1	54,1	61,8	61,4	80,4
–	230	48,3	56,0	56,0	64,0	63,5	83,3
220	–	49,9	57,9	57,9	66,2	65,7	86,1
–	240	51,6	59,8	59,8	68,3	67,9	89,0
230	–	53,2	61,7	61,7	70,5	70,1	91,8
–	250	54,8	63,6	63,6	72,7	72,2	94,7
240	–	56,5	65,5	65,5	74,9	74,4	97,5
250	–	59,7	69,3	69,3	79,2	78,8	103,2

DESIGN VALUES OF ALLOWABLE SHEARING FORCES v_{Rd} [kN/m]

Capacity	h_{min} [mm]	IP 50	IP 55	IP 65	IP 75	IP 90	IP 100
Standard	160		43,5			–	
Q8	160		79,9			–	
Q10	170		124,9			124,9	
Q12	180		179,8			179,8	
Q8X	160		+53,3/-39,9			–	
Q10X	170 180		+83,3/-62,5			+119,9/-62,5	

DIMENSIONS AND ASSIGNMENT

ISOPRO®	IP 50	IP 55	IP 65	IP 75	IP 90	IP 100
Unit length [mm]	1.000					
Tension rods	14 \emptyset 8	11 \emptyset 10	12 \emptyset 10	13 \emptyset 10	10 \emptyset 12	11 \emptyset 12
Tension rods QX	16 \emptyset 8	12 \emptyset 10	13 \emptyset 10	14 \emptyset 10	11 \emptyset 12	12 \emptyset 12
Compression bearings	6	7			8	
Standard shear rods		5 \emptyset 6			–	
Shear rods Q8		6 \emptyset 8			–	
Shear rods Q10		6 \emptyset 10			6 \emptyset 10	
Shear rods Q12		6 \emptyset 12			6 \emptyset 12	
Shear rods Q8X		4 \emptyset 8/3 \emptyset 8			–	
Shear rods Q10X		4 \emptyset 10/3 \emptyset 10			4 \emptyset 12/3 \emptyset 10	

DESIGN TABLE FOR CONCRETE \geq C25/30

DESIGN VALUES OF ALLOWABLE MOMENTS m_{Rd} [kNm/m]

Unit height [mm] depending on cv [mm]		ISOPRO®					
		Concrete \geq C25/30					
35	50	IP 10	IP 15	IP 20	IP 25	IP 35	IP 45
160	–	9,0	13,2	15,4	21,7	23,8	28,0
–	180	9,5	14,0	16,2	22,9	25,1	29,5
170	–	10,0	14,8	17,1	24,1	26,5	31,1
–	190	10,5	15,5	18,0	25,3	27,8	32,7
180	–	11,1	16,3	18,9	26,6	29,2	34,3
–	200	11,6	17,1	19,8	27,8	30,5	35,9
190	–	12,2	17,9	20,7	29,1	31,9	37,5
–	210	12,7	18,6	21,6	30,3	33,3	39,1
200	–	13,3	19,4	22,5	31,6	34,7	40,7
–	220	13,8	20,2	23,4	32,9	36,0	42,3
210	–	14,4	21,0	24,3	34,2	37,5	44,0
–	230	14,9	21,8	25,2	35,4	38,8	45,6
220	–	15,5	22,6	26,2	36,8	40,3	47,3
–	240	16,0	23,4	27,1	38,0	41,7	48,9
230	–	16,6	24,3	28,1	39,4	43,1	50,6
–	250	17,2	25,1	29,0	40,6	44,5	52,2
240	–	17,8	25,9	30,0	42,0	46,0	53,9
250	–	18,9	27,6	31,9	44,7	48,9	57,3

DESIGN VALUES OF ALLOWABLE SHEARING FORCES v_{Rd} [kN/m]

Capacity	h_{min} [mm]	IP 10	IP 15	IP 20	IP 25	IP 35	IP 45
Standard	160	34,8			43,5		
Q8	160	92,7					
Q10	170	144,9					
Q12	180	208,6					
Q8X	160	+61,8/-46,4					
Q10X	170	+96,6/-72,5					

DIMENSIONS AND ASSIGNMENT

ISOPRO®	IP 10	IP 15	IP 20	IP 25	IP 35	IP 45
Unit length [mm]	1.000					
Tension rods	4 \emptyset 8	6 \emptyset 8	7 \emptyset 8	10 \emptyset 8	11 \emptyset 8	13 \emptyset 8
Tension rods QX	5 \emptyset 8	7 \emptyset 8	8 \emptyset 8	12 \emptyset 8	13 \emptyset 8	15 \emptyset 8
Compression bearings	4			5		
Standard shear rods	4 \emptyset 6			5 \emptyset 6		
Shear rods Q8	6 \emptyset 8					
Shear rods Q10	6 \emptyset 10					
Shear rods Q12	6 \emptyset 12					
Shear rods Q8X	4 \emptyset 8/3 \emptyset 8					
Shear rods Q10X	4 \emptyset 10/3 \emptyset 10					

DESIGN TABLE FOR CONCRETE \geq C25/30

DESIGN VALUES OF ALLOWABLE MOMENTS m_{Rd} [kNm/m]

Unit height [mm] depending on cv [mm]		ISOPRO®					
		Concrete \geq C25/30					\geq C30/37
		IP 50	IP 55	IP 65	IP 75	IP 90	IP 100
35	50						
160	–	30,1	36,3	39,5	–	–	–
–	180	31,7	38,3	41,7	–	–	–
170	–	33,4	40,4	44,0	47,6	51,1	57,1
–	190	35,1	42,4	46,2	49,9	53,6	60,0
180	–	36,8	44,6	48,5	52,4	56,1	63,0
–	200	38,5	46,6	50,7	54,8	58,6	65,9
190	–	40,3	48,7	53,0	57,3	61,2	68,9
–	210	42,0	50,8	55,3	59,7	63,7	71,8
200	–	43,7	52,9	57,6	62,2	66,2	74,7
–	220	45,5	55,0	59,8	64,7	68,8	77,6
210	–	47,2	57,2	62,2	67,2	71,3	80,4
–	230	49,0	59,2	64,4	69,6	73,8	83,3
220	–	50,8	61,4	66,8	72,2	76,3	86,1
–	240	52,5	63,5	69,1	74,6	78,9	89,0
230	–	54,3	65,7	71,5	77,2	81,4	91,8
–	250	56,1	67,8	73,8	79,7	83,9	94,7
240	–	57,9	70,1	76,1	82,3	86,5	97,5
250	–	61,5	74,4	80,5	87,4	91,5	103,2

DESIGN VALUES OF ALLOWABLE SHEARING FORCES v_{Rd} [kN/m]

Capacity	h_{min} [mm]	IP 50	IP 55	IP 65	IP 75	IP 90	IP 100
Standard	160		43,5			–	
Q8	160		92,7			–	
Q10	170		144,9			144,9	
Q12	180		208,6			208,6	
Q8X	160		+61,8/-46,4			–	
Q10X	170 180		+96,6/-72,5			+139,0/-72,5	

DIMENSIONS AND ASSIGNMENT

ISOPRO®	IP 50	IP 55	IP 65	IP 75	IP 90	IP 100
Unit length [mm]	1.000					
Tension rods	14 \emptyset 8	11 \emptyset 10	12 \emptyset 10	13 \emptyset 10	10 \emptyset 12	11 \emptyset 12
Tension rods QX	16 \emptyset 8	12 \emptyset 10	13 \emptyset 10	14 \emptyset 10	11 \emptyset 12	12 \emptyset 12
Compression bearings	6	7		8		
Standard shear rods	5 \emptyset 6			–		
Shear rods Q8	6 \emptyset 8			–		
Shear rods Q10	6 \emptyset 10			6 \emptyset 10		
Shear rods Q12	6 \emptyset 12			6 \emptyset 12		
Shear rods Q8X	4 \emptyset 8/3 \emptyset 8			–		
Shear rods Q10X	4 \emptyset 10/3 \emptyset 10			4 \emptyset 12/3 \emptyset 10		

DESIGN TABLE FOR CONCRETE C20/25

DESIGN VALUES OF ALLOWABLE MOMENTS m_{Rd} [kNm/m]

Unit height [mm] depending on c_v [mm]		ISOPRO®	
35	50	IPT 110	IPT 150
180	-	68.3	88.4
-	200	71.6	92.7
190	-	75.0	97.0
-	210	78.3	101.3
200	-	81.7	105.7
-	220	85.0	110.0
210	-	88.3	114.3
-	230	91.7	118.7
220	-	95.0	123.0
-	240	98.4	127.3
230	-	101.7	131.7
-	250	105.1	136.0
240	-	108.4	140.3
-	-	111.8	144.7
250	-	115.1	149.0

DESIGN VALUES OF ALLOWABLE SHEARING FORCES v_{Rd} [kN/m]

Capacity	h_{min} [mm]		IPT 110	IPT 150
Q10	180		83.2	83.2
Q12	180		124.9	119.9
Q14	180	190	179.8	163.1

DIMENSIONS AND ASSIGNMENT

ISOPRO®	IPT 110	IPT 150
Unit length [mm]	500 + 500	
Tension rods	10 Ø 14	14 Ø 14
Pressure rods	14 Ø 12	18 Ø 12
Shear rods Q10	4 Ø 10	
Shear rods Q12	6 Ø 10	4 Ø 12
Shear rods Q14	6 Ø 12	4 Ø 14

DESIGN TABLE FOR CONCRETE \geq C25/30

DESIGN VALUES OF ALLOWABLE MOMENTS m_{Rd} [kNm/m]

Unit height [mm] depending on c_v [mm]		ISOPRO®	
35	50	IPT 110	IPT 150
180	-	68.3	89.2
-	200	71.6	93.6
190	-	75.0	98.0
-	210	78.3	102.4
200	-	81.7	106.7
-	220	85.0	111.1
210	-	88.3	115.5
-	230	91.7	119.8
220	-	95.0	124.2
-	240	98.4	128.6
230	-	101.7	133.0
-	250	105.1	137.3
240	-	108.4	141.7
-	260	111.8	146.1
250	-	115.1	150.5

DESIGN VALUES OF ALLOWABLE SHEARING FORCES v_{Rd} [kN/m]

Capacity	h_{min} [mm]	IPT 110	IPT 150
Q10	180	96.6	96.6
Q12	180	144.9	139.1
Q14	180 190	208.6	189.3

DIMENSIONS AND ASSIGNMENT

ISOPRO®	IPT 110	IPT 150
Unit length [mm]	500 + 500	
Tension rods	10 \emptyset 14	14 \emptyset 14
Pressure rods	14 \emptyset 12	18 \emptyset 12
Shear rods Q10	4 \emptyset 10	
Shear rods Q12	6 \emptyset 10	4 \emptyset 12
Shear rods Q14	6 \emptyset 12	4 \emptyset 14

DEFLECTION AND CAMBER

DEFLECTION

During their construction, cantilevered reinforced concrete structures are elevated to take into account the anticipated deflection. If these structures are thermally separated with ISOPRO® units, when calculating the pre-set, the deflection due to the ISOPRO® unit itself is superimposed with the deflection due to flexion of the slab in accordance with DIN EN 1992-1-1/NA. It must be ensured that the required pre-set is rounded up or down, according to the planned drainage direction. If a drainage system is installed at the building façade, the value must be rounded up, but for drainage at the end of the cantilever arm, it must be rounded down. We recommend providing proof of suitability for use in the serviceability limit state for the quasi-continuous load combination ($\gamma_G = 1,0$, $\gamma_Q = 1,0$, $\psi_2 = 0,3$). The tables below show the deflection factors $\tan \alpha$ for calculating the deflection due to ISOPRO®.

DEFLECTION DUE TO THE ISOPRO® CANTILEVER SLAB CONNECTION

$$w = \tan \alpha \cdot (m_{Ed}/m_{Rd}) \cdot l_k \cdot 10$$

With

w = Deflection at the end of the cantilever arm [mm]

$\tan \alpha$ = Deflection factor, see product sections

m_{Ed} = Bending moment for determining the camber as a result of the ISOPRO® unit. The definitive load combination for the serviceability limit state is determined by the structural engineer

m_{Rd} = Resistance moment of the ISOPRO® unit, see product section

l_k = System length [m]

DEFLECTION FACTOR $\tan \alpha$ FOR CONCRETE C 20/25

ISOPRO®	Concrete covering c_v [mm]	Height h [mm]									
		160	170	180	190	200	210	220	230	240	250
IP 10 to IP 50	35	0,92	0,83	0,76	0,70	0,65	0,61	0,57	0,54	0,51	0,48
	50	–	–	0,87	0,79	0,73	0,68	0,63	0,59	0,55	0,52
IP 55 to IP 90	35	1,02	0,92	0,84	0,77	0,71	0,66	0,62	0,58	0,55	0,52
	50	–	–	0,97	0,88	0,80	0,74	0,69	0,64	0,60	0,56
IPT 110, IPT 150	35	–	–	1,69	1,54	1,42	1,31	1,22	1,14	1,07	1,00
	50	–	–	–	–	1,61	1,48	1,36	1,26	1,18	1,10

DEFLECTION FACTOR $\tan \alpha$ FOR CONCRETE \geq C 25/30

ISOPRO®	Concrete covering c_v [mm]	Height h [mm]									
		160	170	180	190	200	210	220	230	240	250
IP 10 to IP 50	35	0,94	0,85	0,79	0,72	0,67	0,63	0,59	0,56	0,53	0,50
	50	–	–	0,89	0,81	0,75	0,70	0,65	0,61	0,57	0,54
IP 55 to IP 90	35	1,12	1,01	0,93	0,85	0,79	0,74	0,69	0,65	0,61	0,58
	50	–	–	1,06	0,97	0,89	0,82	0,76	0,71	0,67	0,63
IPT 110, IPT 150	35	–	–	1,70	1,55	1,42	1,32	1,22	1,15	1,08	1,00
	50	–	–	–	–	1,62	1,48	1,37	1,27	1,18	1,15

DEFLECTION FACTOR $\tan \alpha$ FOR CONCRETE \geq C 30/37

ISOPRO®	Concrete covering c_v [mm]	Height h [mm]									
		160	170	180	190	200	210	220	230	240	250
IP 100	35	–	1,04	0,95	0,87	0,81	0,75	0,70	0,66	0,62	0,58
	50	–	–	1,09	0,99	0,91	0,84	0,78	0,72	0,68	0,64

BENDING SLENDERNESS – DISTANCE BETWEEN EXPANSION JOINTS

BENDING SLENDERNESS



The bending slenderness is defined as the ratio of the static height d of the balcony slab to the cantilever length l_k . The bending slenderness of a slab has an impact on its vibration characteristics. We therefore recommend limiting the bending slenderness for cantilevered reinforced concrete structures in accordance with DIN EN 1992-1-1 to a maximum value of $l_k/d = 14$. This results in the following maximum recommended cantilever lengths l_k :

Concrete covering	Max. l_k [m] depending on unit height h [mm]									
	160	170	180	190	200	210	220	230	240	250
cv35	1.68	1.82	1.96	2.10	2.24	2.38	2.52	2.66	2.80	2.94
cv50	1.47	1.61	1.75	1.89	2.03	2.17	2.31	2.45	2.59	2.73

DISTANCE BETWEEN EXPANSION JOINTS

If the component dimensions exceed the maximum permissible distance between expansion joints, expansion joints must be arranged perpendicular to the insulation plane. The maximum permissible distance between expansion joints e is dependent on the maximum rod diameter guided across the expansion joint and is thus type-dependent.

The use of fixed points such as corner supports or the use of ISOPRO® IPH or IPE units results in increased constraints, which means the maximum permissible distance between expansion joints must be reduced to $e/2$. Half of the maximum distance between expansion joints is always measured from the fixed point.




Expansion joint layout for different balcony systems

MAXIMUM PERMISSIBLE DISTANCE BETWEEN EXPANSION JOINTS


ISOPRO®	IP 10 to IP 65		IP 75 to IP 100		IPT 110, IPT 150
Shear force capacity	Standard, Q8, Q10, Q8X, Q10X	Q12	Q10	Q12, Q10X	Q10, Q12, Q14
Distance between joints e [m]	13,0	11,3	13,0	11,3	10,1

UNIT STRUCTURE

ISOPRO® IP 10 TO IP 50 - POSITIVE SHEARING FORCES




ISOPRO® IP 10 TO IP 100 - POSITIVE AND NEGATIVE SHEARING FORCES



UNIT STRUCTURE


ISOPRO® IPT110



Length tension/ pressure rod [mm]	IPT 110
tension rod X ₁	960
pressure rod X ₄	385

Length shear rod [mm]	Shear force load-bearing capacity		
	Q10	Q12	Q14
X ₂	560	560	670
X ₃	≤ 640	≤ 640	≤ 745
h _{min}	170	170	180

ISOPRO® IPT150



Length tension/ pressure rod [mm]	IPT 150
tension rod X ₁	960
pressure rod X ₄	385

Length shear rod [mm]	Shear force load-bearing capacity		
	Q10	Q12	Q14
X ₂	560	670	780
X ₃	≤ 640	≤ 745	≤ 860
h _{min}	170	180	190

Our Applications Technology department would be pleased to assist in finding further solutions.

Phone: +49 (0) 7742 9215-300


Fax: +49 (0) 7742 9215-319

E-mail: technik@h-bau.de

SUPPLEMENTARY REINFORCEMENT


ISOPRO® IP 10 TO IP 100

DIRECT SUPPORT





- Item 1 connection reinforcement for the ISOPRO® unit – p. 40
- Item 2 spacing bar 2 Ø 8 balcony side
- Item 3 structural edging parallel to the ISOPRO® IP unit in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications
- Item 4 structural edging at the free balcony edge in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications (not shown here)

INDIRECT SUPPORT



- Item 1 connection reinforcement for the ISOPRO® unit – p. 39
- Item 2 spacing bar 2 x 2 Ø 8 balcony and ceiling side
- Item 3 structural edging parallel to the ISOPRO® IP unit in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications
- Item 4 structural edging at the free balcony edge in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications (not shown here)
- Item 5 Edging or supplementary stirrup - p. 40

EDGING STIRRUP AT THE FREE BALCONY EDGE




ISOPRO® IP – Section A-A

SUPPLEMENTARY REINFORCEMENT


ISOPRO® IPT 110 TO IPT 150

DIREKTE LAGERUNG





- Item 1 connection reinforcement for the ISOPRO® unit – p. 40
- Item 2 spacing bar 2 x Ø 8 balcony side
- Item 3 structural edging parallel to the ISOPRO® IP unit in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications
- Item 4 structural edging at the free balcony edge in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications (not shown here)

INDIRECT SUPPORT



- Item 1 connection reinforcement for the ISOPRO® unit – p. 40
- Item 2 spacing bar 2 x 2 x Ø 8 balcony and ceiling side
- Item 3 structural edging parallel to the ISOPRO® IP unit in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications
- Item 4 structural edging at the free balcony edge in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications (not shown here)
- Item 5 Edging or supplementary stirrup - S. 40

EDGING STIRRUP AT THE FREE BALCONY EDGE



ISOPRO® IPT – Section A-A

SUPPLEMENTARY REINFORCEMENT

CONNECTION REINFORCEMENT ITEM 1

ISOPRO® IP 10 TO IP 100 AND ISOPRO® IPT 110 AND IPT 150

ISOPRO®	$a_{s,erf}$ [cm ² /m]	Suggestion Reinf. steel B500
IP 10	2,37	5 Ø 8
IP 15	3,47	7 Ø 8
IP 20	4,00	8 Ø 8
IP 25	5,62	12 Ø 8
IP 35	6,14	13 Ø 8
IP 45	7,20	15 Ø 8
IP 50	7,73	16 Ø 8
IP 55	9,40	12 Ø 10
IP 65	10,17	13 Ø 10
IP 75	11,04	14 Ø 10
IP 90	11,62	11 Ø 12
IP 100	13,11	12 Ø 12
IPT 110	15,39	10 Ø 14
IPT 150	20,10	14 Ø 14

EDGING / SUPPLEMENTARY STIRRUPS ITEM 5

ISOPRO® IPT 110 AND IPT 150

Shear force load-bearing capacity	ISOPRO®			IPT 110	IPT 150
	IP 10 to IP 20	IP 25 to IP 65	IP 75 to IP 100		
	$a_{s,erf}$ [cm ² /m]	$a_{s,erf}$ [cm ² /m]	$a_{s,erf}$ [cm ² /m]		
Standard	1,13	1,00	–	–	–
Q8	2,13	2,13	–	–	–
Q10	3,33	3,33	3,33	2,22	2,22
Q12	4,79	4,79	4,79	3,33	3,20
Q14	–	–	–	4,79	4,35
Q8X	1,42	1,42	–	–	–
Q10X	2,22	2,22	3,20	–	–

DESIGN EXAMPLE

System:


Cantilever arm

Length of cantilever $l_k = 2,0$ m

Slab thickness balcony = 180 mm

Concrete cover cv35

Concrete class C25/30 balcony and ceiling



Load assumptions:

Dead load $g_k = 4,50$ kN/m²

Superimposed load $g_k = 1,50$ kN/m²

Live load $q_k = 4,00$ kN/m²

Edge load/railing $G_k = 1,50$ kN/m

Edge moment $M_k = 0,00$ kNm/m

Resultant forces:

$$m_{Ed} = (g_k \cdot 1,35 + q_k \cdot 1,5) \cdot l_k^2 / 2 + (G_k \cdot 1,35) \cdot l_k$$

$$v_{Ed} = (g_k \cdot 1,35 + q_k \cdot 1,5) \cdot l_k + (G_k \cdot 1,35)$$

$$m_{Ed} = (6,00 \cdot 1,35 + 4,00 \cdot 1,5) \cdot 2,00^2 / 2 + (1,5 \cdot 1,35) \cdot 2,00 = \underline{32,25 \text{ kNm/m}}$$

$$v_{Ed} = (6,00 \cdot 1,35 + 4,00 \cdot 1,5) \cdot 2,00 + (1,5 \cdot 1,35) = \underline{30,23 \text{ kN/m}}$$

Design:

Chosen: IP 50, cv35, $h = 180$ mm $m_{Rd} = 36,80$ kNm/m $\geq 32,25$ kNm/m (see page 33)

$$v_{Rd} = 43,50 \text{ kN/m} \geq 30,23 \text{ kN/m}$$

Deflection due to thermal insulation unit:

Quasi-permanent load-combination $\Psi_2 = 0,30$, $\gamma_G = 1,00$, $\gamma_Q = 1,00$

$$m_{Ed,perm} = m_{gk} + m_{qk} \cdot \Psi_2$$

$$m_{Ed,perm} = (g_k + q_k \cdot \Psi_2) \cdot l_k^2 / 2 + G_k \cdot l_k$$

$$m_{Ed,perm} = (6,00 + 4,00 \cdot 0,3) \cdot 2,00^2 / 2 + 1,50 \cdot 2,00 = \underline{17,40 \text{ kNm/m}}$$

$$w_1 = \tan \alpha \cdot (m_{Ed,perm} / m_{Rd}) \cdot l_k \cdot 10$$

$$\tan \alpha = 0,79 \text{ (s. Seite 36)}$$

$$w_1 = 0,79 \cdot (17,40 / 36,80) \cdot 2,00 \cdot 10 = \underline{7,47 \text{ mm} (\sim 7,00 \text{ mm})}^*$$

*) w_1 = deflection due to thermal insulation unit. Factor w_2 due to slab deflection has to be added to w_1 by the structural designer. w_2 is in general much smaller than the deflection from the thermal insulation units.

(Rough rule of thumb: $w_2 \sim 0,25 \cdot w_1$)


Camber:

Case 1) Dewatering towards end of cantilever

chosen: camber 7,00 mm (**rounded off**)

Case 2) Dewatering toward building (**rounded up**)

chosen: camber 10,00 mm



ISOPRO® IP two-part


UNITS FOR CANTILEVERED BALCONIES WITH PREFAB SLABS

ISOPRO® IP TWO-PART

- Two-part units for installing the bottom section in element slabs in the prefabricated parts factory and fitting the upper section on the construction site
- For transferring negative moments and positive shearing forces
- Pressure plane with concrete compression bearings
- Load-bearing capacities IP 10 two-part to IP 100 two-part
- Shearing force load-bearing capacities, standard, Q8, Q10 and Q12
- Concrete covering of tension rods cv35 or cv50
- Unit heights depending on the shearing force load-bearing capacity starting from $h_{\min} = 160$ mm
- Fire resistance class REI120 available

TYPE DESIGNATION


IP 65 Q8 cv35 h200 REI120 two-part




APPLICATION – UNIT STRUCTURE



This chapter provides planning aids and specific information about this product. In addition, the general information on materials, design, building physics, installation on site, etc. on pages 10 - 24 has also to be considered.



ISOPRO® IP two-part – Cantilevered balconies



ISOPRO® IP two-part – Installation cross-section thermal insulation composite system

UNIT STRUCTURE ISOPRO® IP 10 TWO-PART TO IP 100 TWO-PART

Length tension rod [mm]	IP10 - IP50	IP55-IP75	IP90-IP100
X ₁	580	720	840

Length Shear rod [mm]	Shearing force load-bearing capacity			
	standard	Q8	Q10	Q12
X ₂	330	450	560	670
X ₃	≤ 475	≤ 530	≤ 640	≤ 745
h _{min}	160	160	170	180


DESIGN AND UNIT STRUCTURE OF THE TWO-PART UNITS

- Design, unit structure and assignment of the units is identical to the corresponding one-part units – p. 30 to 37
- Design of the insulating body comprising a bottom section and a top section.
- Prefabricated parts factories have the option of ordering units in most current heights and doubling them as needed to create additional heights by adding intermediate strips. The shear rod is designed for the basic height and is not raised into the tension plane of the unit.
- Camber, bending slenderness and maximum permissible distance between expansion joints – p. 36 to 37.

SUPPLEMENTARY REINFORCEMENT


ISOPRO® IP 10 TWO-PART TO IP 100 TWO-PART

DIRECT SUPPORT



- Item 1 connection reinforcement for the ISOPRO® unit – p. 45
- Item 2 spacing bar 2 Ø 8 balcony side
- Item 3 structural edging parallel to the ISOPRO® IP unit in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications
- Item 4 structural edging at the free balcony edge in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications (not shown here)

INDIRECT SUPPORT



- Item 1 connection reinforcement for the ISOPRO® unit – p. 45
- Item 2 spacing bar 2 x 2 Ø 8 balcony side
- Item 3 structural edging parallel to the ISOPRO® IP unit in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications
- Item 4 structural edging at the free balcony edge in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications (not shown here)
- Item 5 Edging or supplementary stirrup - S. 45

SUPPLEMENTARY REINFORCEMENT

ISOPRO® IP 10 TWO-PART TO IP 100 TWO-PART


CONNECTION REINFORCEMENT ITEM 1

ISOPRO®	$a_{s,erf}$ [cm ² /m]	Suggestion Reinf. steel B500
IP 10	2,37	5 Ø 8
IP 15	3,47	7 Ø 8
IP 20	4,00	8 Ø 8
IP 25	5,62	12 Ø 8
IP 35	6,14	13 Ø 8
IP 45	7,20	15 Ø 8
IP 50	7,73	16 Ø 8
IP 55	9,40	12 Ø 10
IP 65	10,17	13 Ø 10
IP 75	11,04	15 Ø 10
IP 90	11,62	11 Ø 12
IP 100	13,11	12 Ø 12

EDGE / SUPPLEMENTARY REINFORCEMENT ITEM 5

Shearing force load-bearing capacity	ISOPRO®		
	IP 10 to IP 20	IP 25 to IP 65	IP 75 to IP 100
	$a_{s,erf}$ [cm ² /m]	$a_{s,erf}$ [cm ² /m]	$a_{s,erf}$ [cm ² /m]
Standard	1,13	1,00	–
Q8	2,13	2,13	–
Q10	3,33	3,33	3,33
Q12	4,79	4,79	4,79

INSTALLATION OF TOP SECTION



- The two-part ISOPRO® unit consists of a top section and a bottom section. The bottom section is concreted into the element slab in the prefabricated parts factory.
- The top section is installed on the construction site.
- The top section and bottom section are labelled so that they can be combined correctly. Please make sure you use the right combination on the construction site.
- When fitting the top section, ensure the correct direction of installation is observed.
- Without the top section, the load-bearing capacity of the connection is not guaranteed.



ISOPRO® IP Variants

UNITS FOR CANTILEVERED BALCONIES

ISOPRO® IP VAR.


- For transferring negative moments and positive shearing forces
- Pressure plane with concrete compression bearings
- Load-bearing capacities IP 20, IP 30, IP 50 and IP 65 Q8
- Concrete covering of tension rods cv35 or cv50
- Unit heights depending on the shearing force load-bearing capacity starting from $h_{\min} = 160$ mm
- Fire resistance class REI120 available

CONNECTION GEOMETRY

- Var. I – Connection to a wall, downwards
- Var. II – Connection to a wall, upwards
- Var. III HV – Connection to a ceiling vertically offset upwards
- Var. III UV – Connection to a ceiling vertically offset downwards

TYPE DESIGNATION


IP 65 Q8 cv35 h200 Var. I REI120




APPLICATION

CONNECTION TO A WALL

WALL CONNECTION DOWNWARDS – IP VAR. I




WALL CONNECTION UPWARDS – IP VAR. II



ISOPRO® CONNECTION TO VERTICALLY OFFSET CEILINGS

CONNECTION TO A SLIGHTLY VERTICALLY OFFSET CEILING WITH A STANDARD ISOPRO®



$$v \leq h_D - cv - d_s - cu$$

With

v – Height offset

h_D – Ceiling thickness


cv – Concrete covering of the tension rods of the ISOPRO® unit

d_s – Diameter of the tension rods of the ISOPRO® unit

cu – Concrete covering of the tension rods of the ISOPRO® unit at the bottom edge of ceiling


CONNECTION TO CEILINGS WITH AN OFFSET OF 90 TO 240 MM

HIGHER CEILINGS – IP VAR. III HV



Var. III HV	Height offset [mm]
HV 100	90 - 149
HV 150	150 - 199
HV 200	200 - 240

LOWER CEILINGS – IP VAR. III UV



Var. III UV	Height offset [mm]	Var. III UV	Height offset [mm]
UV 80	≤ 80	UV 150	141 to ≤ 150
UV 90	81 to ≤ 90	UV 160	151 to ≤ 160
UV 100	91 to ≤ 100	UV 170	161 to ≤ 170
UV 110	101 to ≤ 110	UV 180	171 to ≤ 180
UV 120	111 to ≤ 120	UV 190	181 to ≤ 190
UV 130	121 to ≤ 130	UV 200	191 to ≤ 200
UV 140	131 to ≤ 140		

DESIGN TABLE FOR CONCRETE C20/25

DESIGN VALUES OF ALLOWABLE MOMENTS m_{Rd} [kNm/m]

Unit height [mm] depending on c_v [mm]		ISOPRO®			
35	50	IP 20 Var.	IP 30 Var.	IP 50 Var.	IP 65 Q8 Var.
160	–	16,9	20,0	29,8	35,0
–	180	17,8	21,1	31,5	36,9
170	–	18,8	22,2	33,2	38,8
–	190	19,8	23,3	34,9	40,7
180	–	20,8	24,4	36,6	42,6
–	200	21,8	25,5	38,2	44,6
190	–	22,8	26,5	39,8	46,5
–	210	23,8	27,6	41,5	48,4
200	–	24,8	28,7	43,1	50,3
–	220	25,8	29,8	44,7	52,2
210	–	26,8	30,9	46,3	54,1
–	230	27,8	32,0	48,0	56,0
220	–	28,9	33,1	49,6	57,9
–	240	29,9	34,2	51,2	59,8
230	–	30,9	35,3	52,9	61,7
–	250	32,0	36,3	54,5	63,6
240	–	33,0	37,4	56,1	65,5
–	260	35,2	39,6	59,4	69,3
250	–	35,2	48,3	64,1	76,9

DESIGN VALUES OF ALLOWABLE SHEARING FORCES v_{Rd} [kN/m]

Shearing force	h_{min} [mm]	IP 20 Var.	IP 30 Var.	IP 50 Var.	IP 65 Q8 Var.
	160	37,5	45,0	45,0	79,9

DIMENSIONS AND ASSIGNMENT

ISOPRO®	IP 20 Var.	IP 30 Var.	IP 50 Var.	IP 65 Q8 Var.
Unit length [mm]	1000			
Tension rods	5 Ø 10	7 Ø 10	10 Ø 10	12 Ø 10
Compression bearings	4	4	5	6
Shear rods	5 Ø 6	6 Ø 6	6 Ø 6	6 Ø 8

DESIGN TABLE FOR CONCRETE \geq C25/30

DESIGN VALUES OF ALLOWABLE MOMENTS m_{Rd} [kNm/m]

Unit height [mm] depending on cv [mm]		ISOPRO®			
35	50	IP 20 Var.	IP 30 Var.	IP 50 Var.	IP 65 Q8 Var.
160	–	16,9	23,3	29,8	39,5
–	180	17,8	24,5	31,5	41,7
170	–	18,8	25,8	33,2	44,0
–	190	19,8	27,0	34,9	46,2
180	–	20,8	28,3	36,7	48,5
–	200	21,8	29,6	38,4	50,7
190	–	22,8	30,8	40,1	53,0
–	210	23,8	32,1	41,8	55,3
200	–	24,8	33,4	43,6	57,6
–	220	25,8	34,6	45,3	59,8
210	–	26,8	35,9	47,1	62,2
–	230	27,8	37,2	48,8	64,4
220	–	28,9	38,4	50,6	66,8
–	240	29,9	39,7	52,4	69,1
230	–	30,9	41,0	54,2	71,5
–	250	32,0	42,2	55,9	73,8
240	–	33,0	43,5	57,8	76,1
–	260	35,2	46,0	61,4	80,5
250	–	35,2	48,3	66,7	80,0

DESIGN VALUES OF ALLOWABLE SHEARING FORCES v_{Rd} [kN/m]

Shearing force	hmin [mm]	IP 20 Var.	IP 30 Var.	IP 50 Var.	IP 65 Q8 Var.
	160	43.5	52.2	52.2	92.7

DIMENSIONS AND ASSIGNMENT

ISOPRO®	IP 20 Var.	IP 30 Var.	IP 50 Var.	IP 65 Q8 Var.
Unit length [mm]	1000			
Tension rods	5 Ø 10	7 Ø 10	10 Ø 10	12 Ø 10
Pressure rods	4	4	5	6
Shear rods	5 Ø 6	6 Ø 6	6 Ø 6	6 Ø 8



This chapter provides planning aids and specific information about this product. In addition, the general information on materials, design, building physics, installation on site, etc. on pages 10 - 24 has also to be considered.

DEFLECTION AND CAMBER

DEFLECTION

During their construction, cantilevered reinforced concrete structures are elevated to take into account the anticipated deflection. If these structures are thermally separated with ISOPRO® units, when calculating the camber, the deflection due to the ISOPRO® unit itself is superimposed with the deflection due to flexion of the slab in accordance with DIN EN 1992-1-1/NA. It must be ensured that the required camber is rounded up or down, according to the planned drainage direction. If a drainage system is installed at the building façade, the value must be rounded up, but for drainage at the end of the cantilever arm, it must be rounded down. We recommend providing proof of suitability for use in the serviceability limit state for the quasi-continuous load combination ($\gamma_G = 1,0$, $\gamma_Q = 1,0$, $\psi_2 = 0,3$). The tables below show the deflection factors $\tan \alpha$ for calculating the deflection due to ISOPRO®.

DEFLECTION DUE TO THE ISOPRO® CANTILEVER SLAB CONNECTION

$$w = \tan \alpha \cdot (m_{Ed}/m_{Rd}) \cdot l_k \cdot 10$$

With

w = Deflection at the end of the cantilever arm [mm]

$\tan \alpha$ = Deflection factor, see product sections

m_{Ed} = Bending moment for determining the camber as a result of the ISOPRO® unit. The definitive load combination for the serviceability limit state is determined by the structural engineer

m_{Rd} = Resistance moment of the ISOPRO® unit, see product section

l_k = System length [m]

DEFLECTION FACTOR $\tan \alpha$ FOR CONCRETE C 20/25


ISOPRO®	Concrete covering c_v [mm]	Height h [mm]									
		160	170	180	190	200	210	220	230	240	250
IP 20 Var. to IP 65 Q8 Var.	35	0,69	0,62	0,57	0,52	0,48	0,45	0,42	0,40	0,37	0,35
	50	–	–	0,65	0,59	0,54	0,50	0,47	0,43	0,41	0,38

DEFLECTION FACTOR $\tan \alpha$ FOR CONCRETE \geq C 25/30

ISOPRO®	Concrete covering c_v [mm]	Height h [mm]									
		160	170	180	190	200	210	220	230	240	250
IP 20 to IP 50	35	0,73	0,66	0,61	0,56	0,52	0,48	0,45	0,43	0,40	0,38
	50	–	–	0,70	0,63	0,58	0,54	0,50	0,47	0,44	0,41


UNIT STRUCTURE

IP VAR. I




Tension rod [mm]	IP10 - IP50 Var. I	IP65 Var. I
X_1	760	760
X_2	190	190
Length shear rod [mm]	shear force load-bearing capacity standard	
X_3	340	450
X_4	150	190

IP VAR. II




Tension rod [mm]	IP10 - IP50 Var. II	IP65 Var. II
X_1	760	760
Length shear rod [mm]	shear force load-bearing capacity standard	
X_3	340	450
X_4	150	190

IP VAR. III HV



Tension rod [mm]	IP10 - IP50 Var. III HV	IP65 Var. III HV
X_1	760	760
X_2	710	710
Length shear rod [mm]	shear force load-bearing capacity standard	
X_3	340	450
X_4	150	190


IP VAR. III UV



Tension rod [mm]	IP10 - IP50 Var. III UV	IP65 Var. III UV
X_1	760	760
X_2	694	694
Length shear rod [mm]	shear force load-bearing capacity standard	
X_3	340	450
X_4	150	190


SUPPLEMENTARY REINFORCEMENT

CONNECTION TO A WALL, DOWNWARDS – IP VAR. I



- Item 1a connection reinforcement on the balcony for the ISOPRO® unit – see table
- Item 1b connection reinforcement for the ISOPRO® unit to bear the connection moment in the wall in accordance with the structural engineer's specifications
- Item 2 spacing bar 2 Ø 8 on the balcony, 2 Ø 8 in the wall
- Item 3 structural edging parallel to the ISOPRO® unit in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications
- Item 4 (not shown here) slab and wall reinforcement in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications
- The ISOPRO® unit ideally is installed before the wall reinforcement is fitted.

CONNECTION TO A WALL, UPWARDS – IP VAR. II




- Item 1a connection reinforcement on the balcony for the ISOPRO® unit – see table
- Item 1b connection reinforcement for the ISOPRO® unit to bear connection moment and shear force in the wall in accordance with the structural engineer's specifications
- Item 2 spacing bar 2 Ø 8 on the balcony, 3 Ø 8 in the wall
- Item 3 structural edging parallel to the ISOPRO® unit in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications
- Item 4 (not shown here) slab and wall reinforcement in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications
- The ISOPRO® unit ideally is installed before the wall reinforcement is fitted.

CONNECTION REINFORCEMENT ITEM 1

ISOPRO®	IP 20 Var. I	IP 30 Var. I	IP 50 Var. I	IP 65 Q8 Var. I
$a_{s,erf}$ [cm ² /m]	4,44	5,81	7,76	10,17
Suggestion	6 Ø 10	8 Ø 10	10 Ø 10	13 Ø 10



SUPPLEMENTARY REINFORCEMENT

CONNECTION TO A SLIGHTLY VERTICALLY OFFSET CEILING WITH A STANDARD ISOPRO®




- Item 1 connection reinforcement for the ISOPRO® unit - p. 40
- Item 2 spacing bar 2 Ø 8 on the balcony, 3 Ø 8 on the ceiling
- Item 3 structural edging parallel to the ISOPRO® unit in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications
- Item 4 structural edging at the free balcony edge in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications (not shown here)
- Item 5 stirrup for deflecting the tensile force in the joist to the upper tensile reinforcement in accordance with the structural engineer's specifications. The overlap length with the tensile reinforcement must be guaranteed.
- Item 6 Shear reinforcement of the joist in accordance with the structural engineer's specifications.
- The ISOPRO® unit must be installed before the joist reinforcement is fitted.

CONNECTION TO VERTICALLY OFFSET CEILINGS – ISOPRO® IP VAR. III



- Item 1 connection reinforcement for the ISOPRO® unit - see table
- Item 2 spacing bar 2 Ø 8 on the balcony, 3 Ø 8 on the ceiling
- Item 3 structural edging parallel to the ISOPRO® unit in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications
- Item 4 structural edging at the free balcony edge in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications (not shown here)
- Item 5 stirrup for deflecting the tensile force in the joist to the upper tensile reinforcement in accordance with the structural engineer's specifications. The overlap length with the tensile reinforcement must be guaranteed.
- Item 6 Shear reinforcement of the joist in accordance with the structural engineer's specifications.
- The ISOPRO® unit must be installed before the joist reinforcement is fitted.



ISOPRO® IP corner and IPT corner

UNITS FOR CANTILEVERED CORNER BALCONIES

ISOPRO® IP CORNER AND IPT CORNER


- IP corner – Pressure plane with concrete compression bearings
- IPT corner – Pressure plane with steel pressure rods
- Shearing force load-bearing capacity, standard
- A corner unit comprises an EL unit (left corner) in cv35 and an ER unit (right corner) in cv50 and a corner insulation body 80 x 80 mm
- Arranged to the left and right of the ceiling viewpoint
- Unit heights starting from $h_{\min} = 180$ mm
- Fire resistance class REI 120 available for IP corner, R90 available for IPT corner

ISOPRO® IP (T) SUB-UNIT EL/ER

- Sub-unit IP corner – Pressure plane with concrete compression bearings
- IPT corner – Pressure plane with with steel pressure rods
- Shearing force load-bearing capacity, standard
- Concrete covering of tension rods cv35 or cv50
- Unit heights from 180 mm
- Fire resistance class REI 120 available for IP EL and IP ER, R90 available for IPT EL and IPT ER

TYPE DESIGNATION


IP corner 20 cv35 h200 REI120




APPLICATION – UNIT ARRANGEMENT




This chapter provides planning aids and specific information about this product. In addition, the general information on materials, design, building physics, installation on site, etc. on pages 10 - 24 has also to be considered.




ISOPRO® IP corner – Cantilevered external corner balcony




ISOPRO® IP ER – Cantilevered balcony with slab protruding over the support




ISOPRO® IP EL/ER – Installation cross-section cv35



ISOPRO® IP EL/ER – Installation cross-section cv50



ISOPRO® IP corner – Cross-section through the corner situation



ISOPRO® IPT corner – Cross-section through the corner situation

PRODUCT DETAILS

DESIGN VALUES OF ALLOWABLE MOMENTS M_{RD} [kNm] PER SUB-UNIT EL/ER

Unit height [mm] depending on cv [mm]	ISOPRO®					
	IP corner 20		IP corner 30		IPT corner 50	
	C20/25	≥ C25/30	C20/25	≥ C25/30	C20/25	≥ C25/30
35						
180	15.8	17.9	26.1	30.1	28.4	32.3
190	17.5	19.9	28.8	33.4	31.9	36.2
200	19.1	21.9	31.6	36.7	35.4	40.1
210	20.7	23.9	34.3	39.8	38.8	44.1
220	22.4	25.9	37.0	43.0	42.3	48.0
230	24.0	27.9	39.7	46.1	45.8	51.9
240	25.6	29.8	42.4	49.3	49.2	55.9
250	27.3	31.7	45.2	52.5	52.7	59.8

DESIGN VALUES OF ALLOWABLE SHEARING FORCES v_{Rd} [kN] PER SUB-UNIT EL/ER

Shearing force	IP corner 20		IP corner 30		IPT corner 50	
	C20/25	≥ C25/30	C20/25	≥ C25/30	C20/25	≥ C25/30
h = 180 - 190 mm	40.0	46.4	83.2	96.6	83.2	96.6
h = 200 - 250 mm	40.0	46.4	119.9	139.1	119.9	139.1

DIMENSIONS AND ASSIGNMENT

ISOPRO®	IP corner 20	IP corner 30	IPT corner 50
Unit length [mm]	500 + 500	620 + 620	620 + 620
Tension rods	5 Ø 10	6 Ø 12	6 Ø 14
Compression bearings	3 DL	5 DL	steel pressure rods 12 Ø 14
Shear rods h < 200 mm	3 Ø 8	4 Ø 10	4 Ø 10
Shear rods h ≥ 200 mm	3 Ø 8	4 Ø 12	4 Ø 12

NOTES

- With small cantilever arm lengths, a combination of a standard ISOPRO® IP unit in cv35 and an ISOPRO® IP unit in cv50 can also be used instead of the ISOPRO® IP corner unit.
- Sub-units of the corner unit are also available individually for use where high moments and shearing forces occur at specific points
- With an ISOPRO® IP/IPT corner, the IP EL unit is always produced in cv35 and the IP ER unit in cv50. Arranged to the left and right of the ceiling viewpoint.
- Adjoining the ER unit, an ISOPRO® IP unit in cv50 is required when using a corner unit. It is then possible to proceed in cv35 or cv50. The reinforcement can be simplified by continuing in cv50.

DEFLECTION – DISTANCE BETWEEN EXPANSION JOINTS

DEFLECTION

The required camber of the reinforced concrete components is calculated in the same way as for the ISOPRO® units on page 34 using the deflection factors below.

DEFLECTION FACTOR $\tan \alpha$ FOR C 20/25


ISOPRO®	Concrete covering cv [mm]								
		180	190	200	210	220	230	240	250
IP corner 20	35/50	0.97	0.88	0.80	0.74	0.69	0.64	0.60	0.56
IP corner 30	35/50	0.96	0.87	0.79	0.73	0.68	0.63	0.59	0.55
IPT corner 50	35/50	1.53	1.36	1.23	1.12	1.03	0.95	0.88	0.82

DEFLECTION FACTOR $\tan \alpha$ FOR C 25/30

ISOPRO®	Concrete covering cv [mm]								
		180	190	200	210	220	230	240	250
IP corner 20	35/50	1.10	1.00	0.92	0.85	0.79	0.74	0.70	0.65
IP corner 30	35/50	1.10	1.00	0.92	0.85	0.78	0.73	0.68	0.64
IPT corner 50	35/50	1.76	1.56	1.41	1.28	1.18	1.09	1.01	0.94

DISTANCE BETWEEN EXPANSION JOINTS

For balconies that overhang corners, it must be taken into consideration that the corner is a fixed point. This reduces the maximum permissible distance between expansion joints to $e/2$. If the component dimensions exceed the maximum distance between expansion joints, expansion joints must be arranged perpendicular to the insulation plane.




Expansion joint layout for corner balconies

MAXIMUM PERMISSIBLE DISTANCE BETWEEN EXPANSION JOINTS

ISOPRO®	IP 20 corner	IP 30 corner	IPT 50 corner
Distance between joints $e/2$ [m]	6.50	5.65	5.05

UNIT STRUCTURE


ISOPRO® IP CORNER



Length tension rod [mm]	IP20 corner	IP30 corner
X ₁	720	860

Length shear rod [mm]	IP20 corner	IP30 corner
h=180 - 190mm, X ₂	450	560
h=200 - 250mm, X ₂	450	670


ISOPRO® IPT CORNER



Length tension rod [mm]	IPT50 corner
X ₁	980

Length shear rod [mm]	IPT50 corner
h=180 - 190mm, X ₂	560
h=200 - 250mm, X ₂	670


Length steel pressure rod [mm]	IPT50 corner
X ₃	200



ISOPRO® IP corner – Fire protection version, schematic diagram of the insulating body

SUPPLEMENTARY REINFORCEMENT

ISOPRO® IP CORNER




ISOPRO® IP corner – Plan view of supplementary reinforcement, example illustration IP corner 20

SUPPLEMENTARY REINFORCEMENT


ISOPRO® IP CORNER

DIRECT SUPPORT



- Item 1a connection reinforcement and Item 1b additional reinforcement for the ISOPRO® unit – see table
- Item 2 spacing bar 2 Ø 8 on the balcony
- Item 3 structural edging parallel to the ISOPRO® unit in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications
- Item 4 structural edging at the free balcony edge in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications (not shown here)

INDIRECT SUPPORT



- Item 1a connection reinforcement and Item 1b additional reinforcement for the ISOPRO® unit – see table
- Item 2 spacing bar 2 x 2 Ø 8 on the balcony
- Item 3 structural edging parallel to the ISOPRO® unit in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications
- Item 4 structural edging at the free balcony edge in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications (not shown here)
- Item 5 supplementary reinforcement for the ISOPRO® unit - see table

CONNECTION AND ADDITIONAL REINFORCEMENT

ISOPRO®	IP corner 20	IP corner 30	IPT corner 50
Connection reinforcement, item 1a	5 Ø 10	6 Ø 12	5 Ø 14
Rod length, item 1a	$l_k - 70$	$l_k - 70$	$l_k - 70$
Additional reinforcement, item 1b	2 x 5 Ø 10/100	2 x 6 Ø 12/100	2 x 5 Ø 14/100
Rod length, item 1b	2 x l_k	2 x l_k	2 x l_k
Installation area, item 1b	460	570	460
Supp. reinforcement, item 5	–	–	4 Ø 12





ISOPRO® IPQ, IPZQ, IPQS, IPTQS, IPQZ

UNITS FOR SUPPORTED BALCONIES

ISOPRO® IPQ, IPZQ


- For transferring positive shearing forces
- Unit length 1.0 m
- ISOPRO® IPQ pressure plane with concrete compression bearings
- ISOPRO® IPZQ for constraint-free support without pressure components
- Unit heights depending on the load-bearing capacity starting from $h_{\min} = 160$ mm
- Fire resistance class REI120 available

ISOPRO® IPQS/IPTQS, IPQZ


- Short units for load peaks at specific points
- Unit length depending on the load-bearing capacity 0.3 m, 0.4 m or 0.5 m
- ISOPRO® IPQS pressure plane with concrete compression bearings
- ISOPRO® IPTQS pressure plane with steel pressure rods
- ISOPRO® IPQZ for constraint-free support without pressure components
- Load-bearing capacities IPQS/IPQZ 10 to IPTQS/IPQS 75, IPTQS/IPQZ 60, 80,90
- Unit heights depending on the load-bearing capacity starting from $h_{\min} = 160$ mm
- Fire resistance class REI120 available for IPQS and IPQZ, R90 available for IPTQS

TYPE DESIGNATION


IPQ 20 h200 REI120




APPLICATION – UNIT ARRANGEMENT




ISOPRO® IPQ – Supported balcony




ISOPRO® IPQS – Supported balcony with beams and support at specific points with ISOPRO® IPQS units




ISOPRO® IPQ, IPTQQ, IPQS/IPTQS, IPQZ – Loggia balcony with load peaks at specific points and constraint-free support at the front



ISOPRO® IPQ, IPZQ – Pergola with constraint-free support




ISOPRO® IPQ, IPQS – Installation cross-section of thermal insulation composite system




ISOPRO® IPTQS – Installation cross-section of single-leaf masonry

STATIC SYSTEM



ISOPRO® IPQ – Static system



For balconies connected with shear units, appropriate support must be provided in all construction conditions. Temporary supports may only be removed if the permanent supports, which may have been installed at a later date, are sufficiently strong and frictionally connected to the balcony.

DESIGN TABLES

ISOPRO® IPQ – DESIGN VALUES OF ALLOWABLE SHEARING FORCE v_{RD} [kN/m]

ISOPRO®	Shearing force v_{RD} [kN/m]		Unit height [mm]	Unit length [mm]	Shear rods	Compression bearings (CBs)
	C20/25	C25/30			Assignment	Assignment
IPQ 10	30.0	34.8	≥ 160	1000	4 Ø 6*	4 CBs
IPQ 20	37.5	43.5	≥ 160	1000	5 Ø 6*	4 CBs
IPQ 30	44.9	52.2	≥ 160	1000	6 Ø 6*	4 CBs
IPQ 40	59.9	69.5	≥ 160	1000	8 Ø 6*	4 CBs
IPQ 50	74.9	86.9	≥ 160	1000	10 Ø 6*	4 CBs
IPQ 70	79.9	92.7	≥ 160	1000	6 Ø 8	4 CBs
IPQ 80	93.2	108.2	≥ 160	1000	7 Ø 8	4 CBs
IPQ 85	106.5	123.6	≥ 160	1000	8 Ø 8	4 CBs
IPQ 90	133.2	154.5	≥ 160	1000	10 Ø 8	4 CBs
IPQ 100	166.5	193.2	≥ 170	1000	8 Ø 10	4 CBs
IPQ 110	187.3	217.3	≥ 170	1000	9 Ø 10	4 CBs
IPQ 120	208.1	241.5	≥ 170	1000	10 Ø 10	4 CBs

ISOPRO® IPZQ – DESIGN VALUES OF ALLOWABLE SHEARING FORCE v_{RD} [kN/m]

ISOPRO®	Shearing force v_{RD} [kN/m]		Unit height [mm]	Unit length [mm]	Shear rods	Compression bearings (CBs)
	C20/25	C25/30			Assignment	Assignment
IPZQ 10	30.0	34.8	≥ 160	1000	4 Ø 6*	–
IPZQ 20	37.5	43.5	≥ 160	1000	5 Ø 6*	–
IPZQ 30	44.9	52.2	≥ 160	1000	6 Ø 6*	–
IPZQ 40	59.9	69.5	≥ 160	1000	8 Ø 6*	–
IPZQ 50	74.9	86.9	≥ 160	1000	10 Ø 6*	–
IPZQ 70	79.9	92.7	≥ 160	1000	6 Ø 8	–
IPZQ 80	93.2	108.2	≥ 160	1000	7 Ø 8	–
IPZQ 85	106.5	123.6	≥ 160	1000	8 Ø 8	–
IPZQ 90	133.2	154.5	≥ 160	1000	10 Ø 8	–
IPZQ 100	166.5	193.2	≥ 170	1000	8 Ø 10	–
IPZQ 110	187.3	217.3	≥ 170	1000	9 Ø 10	–
IPZQ 120	208.1	241.5	≥ 170	1000	10 Ø 10	–



This chapter provides planning aids and specific information about this product. In addition, the general information on materials, design, building physics, installation on site, etc. on pages 10 - 24 has also to be considered.

DESIGN TABLES

ISOPRO® IPQS/IPTQS – DESIGN VALUES OF ALLOWABLE SHEARING FORCE V_{RD} [kN]

ISOPRO®	Shearing force V_{RD} [kN]		Unit height [mm]	Unit length [mm]	Shear rods	Compression bearings (CBs)/steel pressure rods (SRs)
	C20/25	C25/30			Assignment	Assignment
IPQS 5	22.5	26.1	≥ 160	400	3 Ø 6*	2 CBs
IPQS 10	26.6	30.9	≥ 160	300	2 Ø 8	1 CB
IPQS 15	30.0	34.8	≥ 160	500	4 Ø 6*	2 CBs
IPQS 20	40.0	46.4	≥ 160	400	3 Ø 8	2 CBs
IPQS 30	53.3	61.8	≥ 160	500	4 Ø 8	2 CBs
IPQS 40	41.6	48.3	≥ 170	300	2 Ø 10	1 CB
IPQS 50	62.4	72.4	≥ 170	400	3 Ø 10	2 CBs
IPQS 55	83.2	96.6	≥ 170	500	4 Ø 10	2 CBs
IPTQS 60	59.9	69.5	≥ 180	300	2 Ø 12	SRs 3 Ø 14
IPQS 70	89.9	104.3	≥ 180	400	3 Ø 12	2 CBs
IPQS 75	119.9	139.1	≥ 180	500	4 Ø 12	3 CBs
IPTQS 80	81.6	94.7	≥ 190	300	2 Ø 14	SRs 4 Ø 14
IPTQS 90	122.4	142.0	≥ 190	400	3 Ø 14	SRs 6 Ø 14

ISOPRO® IPQZ – DESIGN VALUES OF ALLOWABLE SHEARING FORCE V_{RD} [kN]

ISOPRO®	Shearing force V_{RD} [kN]		Unit height [mm]	Unit length [mm]	Shear rods	Compression bearings
	C20/25	C25/30			Assignment	Assignment
IPQZ 5	22.5	26.1	≥ 160	400	3 Ø 6*	–
IPQZ 10	26.6	30.9	≥ 160	300	2 Ø 8	–
IPQZ 15	30.0	34.8	≥ 160	500	4 Ø 6*	–
IPQZ 20	40.0	46.4	≥ 160	400	3 Ø 8	–
IPQZ 30	53.3	61.8	≥ 160	500	4 Ø 8	–
IPQZ 40	41.6	48.3	≥ 170	300	2 Ø 10	–
IPQZ 50	62.4	72.4	≥ 170	400	3 Ø 10	–
IPQZ 55	83.2	96.6	≥ 170	500	4 Ø 10	–
IPQZ 60	59.9	69.5	≥ 180	300	2 Ø 12	–
IPQZ 70	89.9	104.3	≥ 180	400	3 Ø 12	–
IPQZ 75	119.9	139.1	≥ 180	500	4 Ø 12	–
IPQZ 80	81.6	94.7	≥ 190	300	2 Ø 14	–
IPQZ 90	122.4	142.0	≥ 190	400	3 Ø 14	–


* Units with shear rods Ø 6 have a looped rod on the ceiling side. For all other units, the shear rod on the ceiling side is straight (see also page 67)

DESIGN


MOMENT RESULTING FROM ECCENTRIC CONNECTIONS

When designing the connection reinforcement on the ceiling for shear units, a moment resulting from eccentric connections must also be considered. This moment is to be superimposed on the moments resulting from the planned loads if the moments are both positive or both negative. The moment is calculated ΔM_{Ed} on the basis of the assumption that the units are fully utilised.

$$\Delta M_{Ed} = V_{Ed} \times z_v$$



ISOPRO® IPQ, IPZQ – Units with concrete compression bearings
 z_v – Lever arm for determining the offset moment



ISOPRO® IPTQS – Units with steel pressure rods
 z_v – Lever arm for determining the offset moment

OFFSET MOMENTS FOR TYPE IPQ, IPZQ

ISOPRO®	Δm_{Ed} [kNm/m]	
	$h \leq 200$ mm	$h \geq 210$ mm
IPQ/IPZQ 10	3.3	5.0
IPQ/IPZQ 20	4.1	6.3
IPQ/IPZQ 30	4.9	7.5
IPQ/IPZQ 40	6.5	10.0
IPQ/IPZQ 50	8.2	12.5
IPQ/IPZQ 70	8.6	13.3
IPQ/IPZQ 80	10.1	15.5
IPQ/IPZQ 85	11.5	17.7
IPQ/IPZQ 90	14.4	22.1
IPQ/IPZQ 100	17.8	27.4
IPQ/IPZQ 110	20.0	30.9
IPQ/IPZQ 120	22.2	34.3

OFFSET MOMENTS FOR TYPE IPQS/IPTQS, IPQZ


ISOPRO®	Δm_{Ed} [kNm/m]	
	$h \leq 200$ mm	$h \geq 210$ mm
IPQS/IPQZ 5	2.5	3.8
IPQS/IPQZ 10	2.9	4.4
IPQS/IPQZ 15	3.3	5.0
IPQS/IPQZ 20	4.3	6.6
IPQS/IPQZ 30	5.7	8.8
IPQS/IPQZ 40	4.4	6.9
IPQS/IPQZ 50	6.7	10.3
IPQS/IPQZ 55	8.9	13.7
IPTQS/IPQZ 60	7,1	8,5
IPQS/IPQZ 70	9.5	14.7
IPQS/IPQZ 75	12.7	19.6
IPTQS/IPQZ 80	10,5	11,5
IPTQS/IPQZ 90	15,8	17,2

MAXIMUM PERMISSIBLE DISTANCE BETWEEN EXPANSION JOINTS

ISOPRO®	IPQ/IPZQ 10 – 120 IPQS/IPQZ 5 – 40, 50, 55	IPQS/IPQZ 45, 70, 75	IPTQS 60, 80, 90
Distance between joints e [m]	13.0	11.3	10.1


UNIT STRUCTURE

ISOPRO® IPQ, IPQS, IPZQ*, IPQZ*, SHEAR ROD Ø 6




Length shear rod [mm]	IPQ 10 - IPQ 50 IPZQ 10 - IPZQ 50 IPQS 5, IPQS 15 IPQZ 5, IPQZ 15
	Ø 6
X ₁	340
X ₂	150
h _{min}	160

ISOPRO® IPQ, IPQS, IPZQ*, IPQZ*, SHEAR ROD ≥ Ø 8



Length shear rod [mm]	IPQ 70 - 90 IPZQ 70 - 90 IPQS 10 - 30 IPQZ10 - 30	IPQ 100 - 120 IPZQ 100 - 120 IPQS 40 - 55 IPQZ 40 - 55	IPQS 70 - 75 IPQZ 60 - 75	IPQZ 80 - 90
	Ø 8	Ø 10	Ø 12	Ø 14
X ₁	450	560	670	780
X ₂	≤ 530	≤ 640	≤ 745	≤ 855
h _{min}	160	170	180	190

ISOPRO® IPTQS, SHEAR ROD ≥ Ø 12



Length shear rod [mm]	IPTQS 60	IPTQS 80 - 90	Length steel pressure rod [mm]	IPTQS 60 IPTQS 80 - 90
	Ø 12	Ø 14		Ø 14
X ₁	670	780	X ₃	165
X ₂	≤ 745	≤ 855		
h _{min}	180	190		


* IPZQ and IPQZ units do not have a pressure plane

NOTES

- The concrete covering of the shear rods at the bottom is generally 30 mm.
- The concrete covering of the shear rods at the top is cv35 to cv85 depending on the height and the rod diameter.


SUPPLEMENTARY REINFORCEMENT

ISOPRO® IPQ, IPZQ, IPQS, IPQZ WITH SHEAR ROD Ø 6 – LOOPED ON THE CEILING SIDE



- Item 1 slab reinforcement in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications
- Item 2 spacing bar 2 Ø 8 on the balcony, 4 Ø 8 on the ceiling
- Item 3 structural edging parallel to the ISOPRO® unit in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications
- Item 4 structural edging at the free balcony edge in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications (not shown here)
- Item 6 stirrup (edge beam) Ø 6/200. For indirect support, a supplementary reinforcement must be arranged on the ceiling side (see table, item 5).

ISOPRO® IPQ, IPZQ, IPQS, IPQZ – SHEAR ROD ON THE CEILING, STRAIGHT



- Item 1 slab reinforcement in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications
- Item 2 spacing bar 2 x 2 Ø 8 on the balcony and ceiling
- Item 3 structural edging parallel to the ISOPRO® unit in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications
- Item 4 structural edging at the free balcony edge in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications (not shown here)
- Item 5 Supplementary reinforcement with indirect support on the ceiling side (see table)


SUPPLEMENTARY REINFORCEMENT ITEM 5

ISOPRO®	Supplementary reinforcement Item 5 $A_{s,erf}$ [cm ²]	
	C20/25	C25/30
IPQ/IPZQ 10	0,69	0,80
IPQ/IPZQ 20	0,86	1,00
IPQ/IPZQ 30	1,03	1,20
IPQ/IPZQ 40	1,38	1,60
IPQ/IPZQ 50	1,72	2,00
IPQ/IPZQ 70	1,84	2,13
IPQ/IPZQ 80	2,14	2,49
IPQ/IPZQ 85	2,45	2,84
IPQ/IPZQ 90	3,06	3,55
IPQ/IPZQ 100	3,83	4,44
IPQ/IPZQ 110	4,31	5,00
IPQ/IPZQ 120	4,78	5,55


ISOPRO®	Supplementary reinforcement Item 5 $A_{s,erf}$ [cm ²]	
	C20/25	C25/30
IPQS/IPQZ 5	0,52	0,60
IPQS/IPQZ 10	0,61	0,71
IPQS/IPQZ 15	0,69	0,80
IPQS/IPQZ 20	0,92	1,07
IPQS/IPQZ 30	1,23	1,42
IPQS/IPQZ 40	0,96	1,11
IPQS/IPQZ 50	1,43	1,66
IPQS/IPQZ 55	1,91	2,22
IPTQS/IPQZ 60	1,36	1,60
IPQS/IPQZ 70	2,07	2,40
IPQS/IPQZ 75	2,76	3,20
IPTQS/IPQZ 80	1,86	2,18
IPTQS/IPQZ 90	2,76	3,26

SUPPLEMENTARY REINFORCEMENT


SUPPLEMENTARY REINFORCEMENT WITH CONSTRAINT-FREE SUPPORT



ISOPRO® IPQ/IPZQ , IPQS/IPQZ – Installation cross-section with opposite types of same load bearing capacity



ISOPRO® IPZQ/IPQ, IPQZ/IPQS – On-site tie rod in the bottom layer of reinforcement – Shear rod $\varnothing 6$ on the ceiling, looped



ISOPRO® IPZQ/IPQ, IPQZ/IPQS – On-site tie rod in the bottom layer of reinforcement – Shear rod on the ceiling, straight

For constraint-free support with an ISOPRO® IPZQ or IPQZ unit, a corresponding IPQ or IPQS unit must be used opposite. A tie rod must be installed between the two units in accordance with the shear reinforcement of the ISOPRO® units.

TIE ROD ISOPRO® IPZQ

ISOPRO®	IPZQ 10	IPZQ 20	IPZQ 30	IPZQ 40	IPZQ 50	IPZQ 70
Tie rod	4 $\varnothing 6$	5 $\varnothing 6$	6 $\varnothing 6$	8 $\varnothing 6$	10 $\varnothing 6$	6 $\varnothing 8$
ISOPRO®	IPZQ 80	IPZQ 85	IPZQ 90	IPZQ 100	IPZQ 110	IPZQ 120
Tie rod	7 $\varnothing 8$	8 $\varnothing 8$	10 $\varnothing 8$	8 $\varnothing 10$	9 $\varnothing 10$	10 $\varnothing 10$

TIE ROD ISOPRO® IPQZ

ISOPRO®	IPQZ 5	IPQZ 10	IPQZ 15	IPQZ 20	IPQZ 30	IPQZ 40
Tie rod	3 $\varnothing 6$	2 $\varnothing 8$	4 $\varnothing 6$	3 $\varnothing 8$	4 $\varnothing 8$	2 $\varnothing 10$
ISOPRO®	IPQZ 50	IPQZ 55	IPQZ 60	IPQZ 70	IPQZ 75	IPQZ 90
Tie rod	3 $\varnothing 10$	4 $\varnothing 10$	2 $\varnothing 12$	3 $\varnothing 12$	4 $\varnothing 12$	2 $\varnothing 14$



ISOPRO® IPTQQ, IPTQQS

UNITS FOR
SUPPORTED BALCONIES
WITH LIFTING LOADS

ISOPRO® IPTQQ


- Unit length 1.0 m
- Type IPTQQ pressure plane with steel pressure rods
- Load-bearing capacities IPTQQ 10 to IPTQQ 110
- For constraint-free support there are also IPZQQ units without steel pressure rods available
- Unit heights depending on diameter of shear rod starting from $h_{\min} = 160$ mm
- Fire resistance class R90 available

ISOPRO® IPTQQS

- Unit length depending on the load-bearing capacity 0.3 m, 0.4 m or 0.5 m
- Type IPTQQS pressure plane with steel pressure rods
- Load-bearing capacities IPTQQS 10 to IPTQQS 90
- For constraint-free support there are also IPZQQS units without steel pressure rods available
- Unit heights depending on diameter of shear rod starting from $h_{\min} = 160$ mm
- Fire resistance class R90 available

TYPE DESIGNATION


IPTQQ 20 h200 R90




APPLICATION – UNIT ARRANGEMENT




This chapter provides planning aids and specific information about this product. In addition, the general information on materials, design, building physics, installation on site, etc. on pages 10 - 24 has also to be considered.




ISOPRO® IPTQQ – Supported balcony with recessed support position




ISOPRO® IPTQQS – Supported balcony with joists and support at specific points with ISOPRO® IPTQQS units




ISOPRO® IPTQQ, IPQS, IPQZ – Loggia balcony with load peaks at specific points at the front and lifting loads in the rear corner area



ISOPRO® IPTQQ – Installation cross-section of single-leaf masonry – Shear rod on the ceiling, looped



ISOPRO® IPTQQ, IPTQQS – Installation cross-section of thermal insulation composite system – Shear rod on the ceiling, straight



For balconies connected with shear units, appropriate support must be provided in all construction conditions. Temporary supports may only be removed if the permanent supports, which may have been installed at a later date, are sufficiently strong and frictionally connected to the balcony.

DESIGN TABLES

ISOPRO® IPTQQ – DESIGN VALUES OF ALLOWABLE SHEARING FORCE v_{Rd} [kN/m]

ISOPRO®	Shearing force v_{Rd} [kN/m]		Unit height [mm]	Unit length [mm]	Shear rods	Compression bearings
	C20/25	C25/30			Assignment	Assignment
IPTQQ 10	± 30.0	± 34.8	≥ 160	1000	2 x 4 Ø 6*	4 Ø 10
IPTQQ 30	± 44.9	± 52.2	≥ 160	1000	2 x 6 Ø 6*	4 Ø 10
IPTQQ 40	± 59.9	± 69.5	≥ 160	1000	2 x 8 Ø 6*	6 Ø 10
IPTQQ 50	± 74.9	± 86.9	≥ 160	1000	2 x 10 Ø 6*	6 Ø 10
IPTQQ 70	± 79.9	± 92.7	≥ 160	1000	2 x 6 Ø 8	6 Ø 10
IPTQQ 90	± 124.9	± 144.9	≥ 170	1000	2 x 6 Ø 10	10 Ø 10
IPTQQ 110	± 179.8	± 208.6	≥ 180	1000	2 x 6 Ø 12	12 Ø 10

* Units with shear rods Ø 6 have a looped rod on the ceiling side. For all other units, the shear rod bar on the ceiling side is straight (see also page 74)


ISOPRO® IPQQS – DESIGN VALUES OF ALLOWABLE SHEARING FORCE V_{Rd} [kN]

ISOPRO®	Shearing force V_{Rd} [kN]		Unit height [mm]	Unit length [mm]	Shear rods	Compression bearings
	C20/25	C25/30			Assignment	Assignment
IPQQS 10	± 26.6	± 30.9	≥ 160	300	2 x 2 Ø 8	2 Ø 10
IPQQS 20	± 40.0	± 46.4	≥ 160	400	2 x 3 Ø 8	3 Ø 10
IPQQS 40	± 41.6	± 48.3	≥ 170	300	2 x 2 Ø 10	3 Ø 10
IPQQS 50	± 62.4	± 72.4	≥ 170	400	2 x 3 Ø 10	4 Ø 10
IPQQS 60	± 59.2	± 69.5	≥ 180	300	2 x 2 Ø 12	4 Ø 10
IPQQS 70	± 89.9	± 104.3	≥ 180	400	2 x 3 Ø 12	6 Ø 10
IPQQS 80	± 80.7	± 94.7	≥ 190	300	2 x 2 Ø 14	4 Ø 14
IPQQS 90	± 120.1	± 142.0	≥ 190	400	2 x 3 Ø 14	6 Ø 14

MOMENTS RESULTING FROM ECCENTRIC CONNECTIONS

MOMENTS RESULTING FROM ECCENTRIC CONNECTIONS

When designing the connection reinforcement on the ceiling for the ISOPRO® IPTQQ and IPTQQS shear units, a moment resulting from eccentric connections must also be considered. This moment is to be superimposed on the moments resulting from the planned loads if the moments are both positive or both negative. The moment is calculated ΔM_{Ed} on the basis of the assumption that the units are fully utilised.



$$\Delta M_{Ed} = V_{Ed} \times z_v$$

ISOPRO® IPTQQ, IPTQQS – Units with steel pressure rods
 z_v – Lever arm for determining the offset moment

OFFSET MOMENTS FOR TYPE IPTQQ

ISOPRO®	Δm_{Ed} [kNm/m]	
	$h < 200$ mm	$h \geq 200$ mm
IPTQQ 10	3.0	4.4
IPTQQ 30	4.5	6.6
IPTQQ 40	6.1	8.8
IPTQQ 50	7.6	11.0
IPTQQ 70	8.0	11.7
IPTQQ 90	13.8	18.1
IPTQQ 110	19.8	26.1

OFFSET MOMENTS FOR TYPE IPTQQS


ISOPRO®	Δm_{Ed} [kNm/m]	
	$h < 200$ mm	$h \geq 200$ mm
IPTQQS 10	2.7	3.9
IPTQQS 20	4.0	5.9
IPTQQS 40	4.6	6.0
IPTQQS 50	6.9	9.1
IPTQQS 60	7.2	8.6
IPTQQS 70	10.9	12.9
IPTQQS 80	10.5	11.5
IPTQQS 90	15.8	17.2

MAXIMUM PERMISSIBLE DISTANCE BETWEEN EXPANSION JOINTS

ISOPRO®	IPTQQ 10 – 90 IPTQQS 10 – 50	IPTQQ 110 IPTQQS 60 + 70	IPTQQS 80 + 90
Distance between joints e [m]	13.0	11.3	10.1


UNIT STRUCTURE

ISOPRO® IPTQQ - SHEAR ROD Ø 6



Length shear rod [mm]	IPTQQ10 to IPTQQ50
	Ø 6
X ₁	340
X ₂	150
h _{min}	160
Length pressure rod [mm]	IPTQQ10 to IPTQQ50
	pressure rod Ø 10
X ₃	150

ISOPRO® IPTQQ, IPTQQS - SHEAR ROD ≥ Ø 8




Length shear rod [mm]	IPTQQ70 IPTQQS10 IPTQQS20	IPTQQ90 IPTQQS40 IPTQQS50	IPTQQ110 IPTQQS60 IPTQQS70	IPTQQS80 IPTQQS90
		Ø 8	Ø 10	Ø 12
X ₁	450	560	670	780
X ₂	≤ 530	≤ 640	≤ 745	≤ 855
h _{min}	160	170	180	190
Length pressure rod [mm]	IPTQQ70 - 110 IPTQQS10 - 70		IPTQQS80 - 90	
	Ø 10		Ø 14	
X ₃	150		165	

NOTES

- The concrete covering of the shear rods at the bottom is generally 30 mm.
- The concrete covering of the shear rods at the top is cv35 to cv85 depending on the height and the rod diameter.


SUPPLEMENTARY REINFORCEMENT

ISOPRO® IPTQQ 10 - 50 WITH SHEAR ROD Ø 6 – LOOPED ON THE CEILING



- Item 1 slab reinforcement and edging in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications
- Item 2 spacing bar 2 Ø 8 on the balcony, 4 Ø 8 on the ceiling
- Item 4 structural edging at the free balcony edge in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications (not shown here)
- Item 5 supplementary reinforcement – see table below
- Item 6 stirrup (edge beam) Ø 6/200

ISOPRO® IPTQQ 70 - 110, IPTQQS 10 - 90 – SHEAR ROD STRAIGHT ON THE CEILING



- Item 1 slab reinforcement and edging in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications
- Item 2 spacing bar 2 x 2 Ø 8 on the balcony and ceiling
- Item 4 structural edging at the free balcony edge in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications (not shown here)
- Item 5a supplementary reinforcement balcony side – see table below
- Item 5b supplementary reinforcement with indirect support on the ceiling side (see table)

SUPPLEMENTARY REINFORCEMENT

ISOPRO® IPTQQ

ISOPRO®	Supplementary reinforcement, item 5 $a_{s,erf}$ [cm ² /m]	
	C20/25	C25/30
IPTQQ 10	0.69	0.80
IPTQQ 30	1.03	1.20
IPTQQ 40	1.38	1.60
IPTQQ 50	1.72	2.00
IPTQQ 70	1.84	2.13
IPTQQ 90	2.87	3.33
IPTQQ 110	4.13	4.80

ISOPRO® IPTQQS

ISOPRO®	Supplementary reinforcement item 5 $A_{s,erf}$ [cm ²]	
	C20/25	C25/30
IPTQQS 10	0.61	0.71
IPTQQS 20	0.92	1.07
IPTQQS 40	0.96	1.11
IPTQQS 50	1.43	1.66
IPTQQS 60	1.36	1.60
IPTQQS 70	2.07	2.40
IPTQQS 80	1.86	2.18
IPTQQS 90	2.76	3.26



ISOPRO® IPTD


UNITS FOR
CONTINUOUS
SLABS

ISOPRO® IPTD

- For transferring positive and negative moments and positive and negative shearing forces
- Tension and pressure plane with steel tension/pressure rods
- Load-bearing capacities IPTD 20 to IPTD 100
- Shearing force load-bearing capacities, standard, Q8 and Q10
- Concrete covering of tension rods cv35 or cv50
- Concrete covering of the pressure rods at the bottom 30 mm for cv35 and 50 mm for cv50
- Unit heights depending on the shearing force load-bearing capacity starting from $h_{\min} = 160$ mm
- Fire resistance class R90 available

TYPE DESIGNATION


IPTD 50 Q8 cv35 h200 R90




APPLICATION – UNIT ARRANGEMENT




This chapter provides planning aids and specific information about this product. In addition, the general information on materials, design, building physics, installation on site, etc. on pages 10 - 24 has also to be considered.




ISOPRO® IPTD – Continuous slab with a glass façade



ISOPRO® IPTD – Internal corner balcony with large dimensions and loads




ISOPRO® IPTD – Inset balcony with glass façade, without direct support



ISOPRO® IPTD – Installation cross-section of glass façade

NOTE FOR DESIGN

- The gap between the balcony and the ceiling slab must be taken into account for the calculation in the FEM program
- With the ISOPRO® IPTD units only bending moments perpendicular to the insulation joint can be transferred
- When calculating the resultant forces, the spring stiffness of the ISOPRO® IPTD units must be iteratively included in the calculation. First, an assumption is made for the spring stiffness of the thermal insulation unit. A unit is then selected via the resulting static design values. In the next step, the definitive spring stiffness of the selected unit is included in the calculation. Possibly another iterative step is required to come to final solution.
- To transfer forces parallel and perpendicular to the joint, the IPTD units can be combined with ISOPRO® IPE units.



ISOPRO® IPTD – Static System

DESIGN TABLE FOR CONCRETE C 20/25

DESIGN VALUES OF ALLOWABLE MOMENTS m_{Rd} [kNm/m]

Unit height [mm] depending on c_v [mm]		ISOPRO®								
35	50	IPTD 20	IPTD 20 Q8	IPTD 20 Q10	IPTD 30	IPTD 30 Q8	IPTD 30 Q10	IPTD 50	IPTD 50 Q8	IPTD 50 Q10
160	-	± 15.0	± 13.5	-	± 22.3	± 20.9	-	± 30.4	± 29.0	-
-	200	± 15.8	± 14.3	-	± 23.7	± 22.1	-	± 32.2	± 30.7	-
170	-	± 16.7	± 15.1	± 13.4	± 25.0	± 23.4	± 21.8	± 34.1	± 32.4	± 30.8
-	210	± 17.6	± 15.9	± 14.1	± 26.4	± 24.7	± 22.9	± 35.9	± 34.2	± 32.5
180	-	± 18.5	± 16.7	± 14.8	± 27.7	± 25.9	± 24.1	± 37.7	± 35.9	± 34.1
-	220	± 19.4	± 17.4	± 15.5	± 29.1	± 27.2	± 25.3	± 39.6	± 37.7	± 35.8
190	-	± 20.3	± 18.2	± 16.2	± 30.4	± 28.4	± 26.5	± 41.4	± 39.4	± 37.4
-	230	± 21.1	± 19.0	± 16.9	± 31.8	± 29.7	± 27.6	± 43.2	± 41.2	± 39.1
200	-	± 22.0	± 19.8	± 17.6	± 33.1	± 30.9	± 28.8	± 45.1	± 42.9	± 40.7
-	240	± 22.9	± 20.6	± 18.3	± 34.4	± 32.2	± 30.0	± 46.9	± 44.6	± 42.4
210	-	± 23.8	± 21.4	± 19.0	± 35.8	± 33.5	± 31.1	± 48.7	± 46.4	± 44.1
-	250	± 24.7	± 22.2	± 19.8	± 37.1	± 34.7	± 32.3	± 50.5	± 48.1	± 45.7
220	-	± 25.5	± 23.0	± 20.5	± 38.5	± 36.0	± 33.5	± 52.4	± 49.9	± 47.4
-	-	± 26.4	± 23.8	± 21.2	± 39.8	± 37.2	± 34.6	± 54.2	± 51.6	± 49.0
230	-	± 27.3	± 24.6	± 21.9	± 41.2	± 38.5	± 35.8	± 56.0	± 53.4	± 50.7
-	-	± 28.2	± 25.4	± 22.6	± 42.5	± 39.8	± 37.0	± 57.9	± 55.1	± 52.3
240	-	± 29.1	± 26.2	± 23.3	± 43.9	± 41.0	± 38.2	± 59.7	± 56.9	± 54.0
-	-	± 29.9	± 27.0	± 24.0	± 45.2	± 42.3	± 39.3	± 61.5	± 58.6	± 55.7
250	-	± 30.8	± 27.8	± 24.7	± 46.6	± 43.5	± 40.5	± 63.4	± 60.3	± 57.3

DESIGN VALUES OF ALLOWABLE SHEARING FORCES v_{Rd} [kN/m]

ISOPRO®	IPTD 20	IPTD 20 Q8	IPTD 20 Q10	IPTD 30	IPTD 30 Q8	IPTD 30 Q10	IPTD 50	IPTD 50 Q8	IPTD 50 Q10
Shearing force v_{Rd} [kN/m]	± 45.0	± 80.0	± 115.0	± 45.0	± 80.0	± 115.0	± 45.0	± 80.0	± 115.0

DIMENSIONS AND ASSIGNMENT

ISOPRO®	IPTD 20	IPTD 20 Q8	IPTD 20 Q10	IPTD 30	IPTD 30 Q8	IPTD 30 Q10	IPTD 50	IPTD 50 Q8	IPTD 50 Q10
Unit length [mm]	1000								
Tension/pressure rods	6 Ø 10			6 Ø 12			8 Ø 12		
Shear rods	2 x 4 Ø 8	2 x 6 Ø 8	2 x 6 Ø 10	2 x 4 Ø 8	2 x 6 Ø 8	2 x 6 Ø 10	2 x 4 Ø 8	2 x 6 Ø 8	2 x 6 Ø 10

DESIGN TABLE FOR CONCRETE C 20/25

DESIGN VALUES OF ALLOWABLE MOMENTS m_{Rd} [kNm/m]

Unit height [mm] depending on c_v [mm]		ISOPRO®								
35	50	IPTD 70	IPTD 70 Q8	IPTD 70 Q10	IPTD 90	IPTD 90 Q8	IPTD 90 Q10	IPT 100	IPTD 100 Q8	IPTD 100 Q10
160	-	± 38.5	± 37.0	-	± 46.5	± 45.1	-	± 50.3	-	-
-	200	± 40.8	± 39.2	-	± 49.3	± 47.8	-	± 53.4	-	-
170	-	± 43.1	± 41.5	± 39.9	± 52.1	± 50.5	± 48.9	± 56.5	± 54.9	-
-	210	± 45.4	± 43.7	± 42.0	± 54.9	± 53.2	± 51.5	± 59.6	± 58.0	-
180	-	± 47.7	± 45.9	± 44.1	± 57.8	± 55.9	± 54.1	± 62.7	± 61.0	± 59.1
-	220	± 50.1	± 48.2	± 46.3	± 60.6	± 58.7	± 56.8	± 65.8	± 64.0	± 62.0
190	-	± 52.4	± 50.4	± 48.4	± 63.4	± 61.4	± 59.4	± 69.0	± 67.0	± 65.0
-	230	± 54.7	± 52.6	± 50.6	± 66.2	± 64.1	± 62.0	± 72.1	± 70.0	± 67.9
200	-	± 57.0	± 54.9	± 52.7	± 69.0	± 66.8	± 64.7	± 75.2	± 73.0	± 70.8
-	240	± 59.3	± 57.1	± 54.8	± 71.8	± 69.5	± 67.3	± 78.3	± 76.1	± 73.7
210	-	± 61.6	± 59.3	± 57.0	± 74.6	± 72.2	± 69.9	± 81.4	± 79.1	± 76.7
-	250	± 64.0	± 61.5	± 59.1	± 77.4	± 75.0	± 72.5	± 84.5	± 82.1	± 79.6
220	-	± 66.3	± 63.8	± 61.3	± 80.2	± 77.7	± 75.2	± 87.6	± 85.1	± 82.5
-	-	± 68.6	± 66.0	± 63.4	± 83.0	± 80.4	± 77.8	± 90.7	± 88.1	± 85.4
230	-	± 70.9	± 68.2	± 65.6	± 85.8	± 83.1	± 80.4	± 93.8	± 91.2	± 88.4
-	-	± 73.2	± 70.5	± 67.7	± 88.6	± 85.8	± 83.1	± 96.9	± 94.2	± 91.3
240	-	± 75.6	± 72.7	± 69.8	± 91.4	± 88.5	± 85.7	± 100.0	± 97.2	± 94.2
-	-	± 77.9	± 74.9	± 72.0	± 94.2	± 91.3	± 88.3	± 103.1	± 100.2	± 97.1
250	-	± 80.2	± 77.2	± 74.1	± 97.0	± 94.0	± 90.9	± 106.2	± 103.2	± 100.1

DESIGN VALUES OF ALLOWABLE SHEARING FORCES v_{Rd} [kN/m]

ISOPRO®	IPTD 70	IPTD 70 Q8	IPTD 70 Q10	IPTD 90	IPTD 90 Q8	IPTD 90 Q10	IPT 100	IPTD 100 Q8	IPTD 100 Q10
Shearing force v_{Rd} [kN/m]	± 45.0	± 80.0	± 115.0	± 45.0	± 80.0	± 115.0	± 80.0	± 115.0	± 152.0

DIMENSIONS AND ASSIGNMENT

ISOPRO®	IPTD 70	IPTD 70 Q8	IPTD 70 Q10	IPTD 90	IPTD 90 Q8	IPTD 90 Q10	IPT 100	IPTD 100 Q8	IPTD 100 Q10
Unit length [mm]	1000								
Tension/pressure rods	10 Ø 12			12 Ø 12			12 Ø 14		
Shear rods	2 x 4 Ø 8	2 x 6 Ø 8	2 x 6 Ø 10	2 x 4 Ø 8	2 x 6 Ø 8	2 x 6 Ø 10	2 x 6 Ø 8	2 x 6 Ø 10	2 x 6 Ø 12

DESIGN TABLE FOR CONCRETE \geq C25/30

DESIGN VALUES OF ALLOWABLE MOMENTS m_{Rd} [kNm/m]

Unit height [mm] depending on c_v [mm]		ISOPRO®								
35	50	IPTD 20	IPTD 20 Q8	IPTD 20 Q10	IPTD 30	IPTD 30 Q8	IPTD 30 Q10	IPTD 50	IPTD 50 Q8	IPTD 50 Q10
160	-	± 14.6	± 13.0	-	± 22.0	± 20.4	-	± 30.1	± 28.5	-
-	200	± 15.5	± 13.7	-	± 23.3	± 21.6	-	± 31.9	± 30.2	-
170	-	± 16.3	± 14.5	± 12.5	± 24.7	± 22.8	± 20.8	± 33.7	± 31.9	± 29.9
-	210	± 17.2	± 15.3	± 13.1	± 26.0	± 24.1	± 22.0	± 35.5	± 33.6	± 31.5
180	-	± 18.1	± 16.0	± 13.8	± 27.3	± 25.3	± 23.1	± 37.3	± 35.3	± 33.1
-	220	± 18.9	± 16.8	± 14.4	± 28.6	± 26.5	± 24.2	± 39.1	± 37.0	± 34.7
190	-	± 19.8	± 17.5	± 15.1	± 30.0	± 27.8	± 25.3	± 40.9	± 38.7	± 36.3
-	230	± 20.7	± 18.3	± 15.7	± 31.3	± 29.0	± 26.4	± 42.8	± 40.5	± 37.9
200	-	± 21.5	± 19.1	± 16.4	± 32.6	± 30.2	± 27.6	± 44.6	± 42.2	± 39.5
-	240	± 22.4	± 19.8	± 17.0	± 33.9	± 31.4	± 28.7	± 46.4	± 43.9	± 41.1
210	-	± 23.2	± 20.6	± 17.7	± 35.3	± 32.7	± 29.8	± 48.2	± 45.6	± 42.7
-	250	± 24.1	± 21.4	± 18.4	± 36.6	± 33.9	± 30.9	± 50.0	± 47.3	± 44.3
220	-	± 25.0	± 22.1	± 19.0	± 37.9	± 35.1	± 32.0	± 51.8	± 49.0	± 45.9
-	-	± 25.8	± 22.9	± 19.7	± 39.2	± 36.3	± 33.2	± 53.6	± 50.7	± 47.6
230	-	± 26.7	± 23.7	± 20.3	± 40.6	± 37.6	± 34.3	± 55.4	± 52.4	± 49.2
-	-	± 27.5	± 24.4	± 21.0	± 41.9	± 38.8	± 35.4	± 57.2	± 54.2	± 50.8
240	-	± 28.4	± 25.2	± 21.6	± 43.2	± 40.0	± 36.5	± 59.1	± 55.9	± 52.4
-	-	± 29.3	± 25.9	± 22.3	± 44.5	± 41.3	± 37.6	± 60.9	± 57.6	± 54.0
250	-	± 30.1	± 26.7	± 22.9	± 45.9	± 42.5	± 38.8	± 62.7	± 59.3	± 55.6

DESIGN VALUES OF ALLOWABLE SHEARING FORCES v_{Rd} [kN/m]

ISOPRO®	IPTD 20	IPTD 20 Q8	IPTD 20 Q10	IPTD 30	IPTD 30 Q8	IPTD 30 Q10	IPTD 50	IPTD 50 Q8	IPTD 50 Q10
Shearing force v_{Rd} [kN/m]	± 53.0	± 92.0	± 135.0	± 53.0	± 92.0	± 135.0	± 53.0	± 92.0	± 135.0

DIMENSIONS AND ASSIGNMENT

ISOPRO®	IPTD 20	IPTD 20 Q8	IPTD 20 Q10	IPTD 30	IPTD 30 Q8	IPTD 30 Q10	IPTD 50	IPTD 50 Q8	IPTD 50 Q10
Unit length [mm]	1000								
Tension/pressure rods	6 \emptyset 10			6 \emptyset 12			8 \emptyset 12		
Shear rods	2 x 4 \emptyset 8	2 x 6 \emptyset 8	2 x 6 \emptyset 10	2 x 4 \emptyset 8	2 x 6 \emptyset 8	2 x 6 \emptyset 10	2 x 4 \emptyset 8	2 x 6 \emptyset 8	2 x 6 \emptyset 10

DESIGN TABLE FOR CONCRETE \geq C25/30

DESIGN VALUES OF ALLOWABLE MOMENTS m_{Rd} [kNm/m]

Unit height [mm] depending on c_v [mm]		ISOPRO®								
35	50	IPTD 70	IPTD 70 Q8	IPTD 70 Q10	IPTD 90	IPTD 90 Q8	IPTD 90 Q10	IPT 100	IPTD 100 Q8	IPTD 100 Q10
160	-	± 38.1	± 36.5	-	± 46.2	± 44.6	-	± 49.8	-	-
-	200	± 40.4	± 38.7	-	± 49.0	± 47.3	-	± 52.9	-	-
170	-	± 42.7	± 40.9	± 38.9	± 51.8	± 50.0	± 48.0	± 56.0	± 54.0	-
-	210	± 45.0	± 43.1	± 41.0	± 54.6	± 52.6	± 50.5	± 59.1	± 57.0	-
180	-	± 47.3	± 45.3	± 43.1	± 57.3	± 55.3	± 53.1	± 62.1	± 60.0	± 57.7
-	220	± 49.6	± 47.5	± 45.2	± 60.1	± 58.0	± 55.7	± 65.2	± 62.9	± 60.5
190	-	± 51.9	± 49.7	± 47.3	± 62.9	± 60.7	± 58.3	± 68.3	± 65.9	± 63.4
-	230	± 54.2	± 51.9	± 49.4	± 65.7	± 63.4	± 60.9	± 71.4	± 68.9	± 66.3
200	-	± 56.5	± 54.1	± 51.5	± 68.5	± 66.1	± 63.4	± 74.4	± 71.8	± 69.1
-	240	± 58.8	± 56.3	± 53.6	± 71.3	± 68.8	± 66.0	± 77.5	± 74.8	± 72.0
210	-	± 61.1	± 58.5	± 55.7	± 74.0	± 71.4	± 68.6	± 80.6	± 77.8	± 74.8
-	250	± 63.4	± 60.7	± 57.8	± 76.8	± 74.1	± 71.2	± 83.7	± 80.7	± 77.7
220	-	± 65.7	± 62.9	± 59.8	± 79.6	± 76.8	± 73.7	± 86.7	± 83.7	± 80.5
-	-	± 68.0	± 65.1	± 61.9	± 82.4	± 79.5	± 76.3	± 89.8	± 86.7	± 83.4
230	-	± 70.3	± 67.3	± 64.0	± 85.2	± 82.2	± 78.9	± 92.9	± 89.6	± 86.3
-	-	± 72.6	± 69.5	± 66.1	± 88.0	± 84.9	± 81.5	± 96.0	± 92.6	± 89.1
240	-	± 74.9	± 71.7	± 68.2	± 90.7	± 87.6	± 84.1	± 99.0	± 95.6	± 92.0
-	-	± 77.2	± 73.9	± 70.3	± 93.5	± 90.2	± 86.6	± 102.1	± 98.6	± 94.8
250	-	± 79.5	± 76.1	± 72.4	± 96.3	± 92.9	± 89.2	± 105.2	± 101.5	± 97.7

DESIGN VALUES OF ALLOWABLE SHEARING FORCES v_{Rd} [kN/m]

ISOPRO®	IPTD 70	IPTD 70 Q8	IPTD 70 Q10	IPTD 90	IPTD 90 Q8	IPTD 90 Q10	IPT 100	IPTD 100 Q8	IPTD 100 Q10
Shearing force v_{Rd} [kN/m]	± 53.0	± 92.0	± 135.0	± 53.0	± 92.0	± 135.0	± 92.0	± 135.0	± 180.0

DIMENSIONS AND ASSIGNMENT

ISOPRO®	IPTD 70	IPTD 70 Q8	IPTD 70 Q10	IPTD 90	IPTD 90 Q8	IPTD 90 Q10	IPT 100	IPTD 100 Q8	IPTD 100 Q10
Unit length [mm]	1000								
Tension/pressure rods	10 \emptyset 12			12 \emptyset 12			12 \emptyset 14		
Shear rods	2 x 4 \emptyset 8	2 x 6 \emptyset 8	2 x 6 \emptyset 10	2 x 4 \emptyset 8	2 x 6 \emptyset 8	2 x 6 \emptyset 10	2 x 6 \emptyset 8	2 x 6 \emptyset 10	2 x 6 \emptyset 12


DESIGN - UNIT STRUCTURE

MAXIMUM PERMISSIBLE DISTANCE BETWEEN EXPANSION JOINTS

ISOPRO®	IPTD 20	IPTD 30 to IPTD 90	IPTD 100
Distance between joints e [m]	13.0	11.3	10.1

UNIT STRUCTURE

ISOPRO® IPTD




Length tension and pressure rod [mm]	IPTD 20	IPTD 30	IPTD 50	IPTD 70	IPTD 90	IPTD 100
X_1	740	860	860	860	860	980

Length shear rod [mm]	IPTD 20 to IPTD 90 Shear force load-bearing capacity			IPTD 100 Shear force load-bearing capacity		
	Standard	Q8	Q10	Standard	Q8	Q10
X_3	450	450	560	450	560	670
X_4	≤ 530	≤ 530	≤ 640	≤ 530	≤ 640	≤ 750
h_{min}	160	160	170	160	170	180

SUPPLEMENTARY REINFORCEMENT

ISOPRO® IPTD



- Item 1 connection reinforcement for the ISOPRO® unit – for negative moments at the top, for positive moments at the bottom – see table
- Item 2 spacing bar 2 x 2 Ø 8 on balcony and ceiling side
- Item 4 structural edging at the free balcony edge in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications (not shown here)
- Item 5 supplementary reinforcement on balcony and ceiling side – see table below

CONNECTION REINFORCEMENT ITEM 1

ISOPRO®	IPTD 20	IPTD 30	IPTD 50	IPTD 70	IPTD 90	IPTD 100
$a_{s,erf}$ [cm ² /m]	4.71	6.79	9.05	11.31	13.57	18.47
Suggestion	6 Ø 10	6 Ø 12	8 Ø 12	10 Ø 12	12 Ø 12	12 Ø 14

SUPPLEMENTARY REINFORCEMENT ITEM 5

ISOPRO®	IPTD 20 to IPTD 90			IPTD 100		
	Standard	Q8	Q10	Standard	Q8	Q10
$a_{s,erf}$ [cm ² /m]	1.21	2.13	3.10	2.13	3.10	4.14
Suggestion	Ø 6/200	Ø 8/200	Ø 10/200	Ø 8/200	Ø 10/200	Ø 10/150



ISOPRO® IPH


UNITS FOR PLANNED HORIZONTAL LOADS

ISOPRO® IPH

- Load-bearing capacities IPH 1, IPH 2 and IPH 3
- ISOPRO® IPH 1 for transferring horizontal forces parallel to the insulating joint
- ISOPRO® IPH 2 for transferring horizontal forces perpendicular to the insulating joint
- ISOPRO® IPH 3 for transferring horizontal forces parallel and perpendicular to the insulating joint
- Clearly defined concrete covering, see product details
- Unit heights starting from $h_{\min} = 160$ mm
- Fire resistance class REI120 available

TYPE DESIGNATION


IPH 2 h200 REI120




APPLICATION – UNIT ARRANGEMENT




This chapter provides planning aids and specific information about this product. In addition, the general information on materials, design, building physics, installation on site, etc. on pages 10 - 24 has also to be considered.




ISOPRO® IPH – Cantilevered balcony with planned horizontal loads



ISOPRO® IPH – Supported internal corner balcony with planned horizontal loads




ISOPRO® IPH – Balcony on hinged supports with IPH structural units




ISOPRO® IPH 3 – Installation cross-section of thermal insulation composite system

DESIGN VALUES OF ALLOWABLE HORIZONTAL LOADS H_{Rd} [kN]


ISOPRO®	IPH 1		IPH 2		IPH 3	
	C 20/25	C 25/30	C 20/25	C 25/30	C 20/25	C 25/30
Horizontal force, parallel $H_{Rd }$ [kN]	± 7.4	± 7.4	–	–	± 7.4	± 7.4
Horizontal force, vertical $H_{Rd\perp}$ [kN]	–	–	± 18.1	± 18.1	± 18.1	± 18.1



IPH 1



IPH 2




IPH 3

DESIGN - EXPANSION JOINTS


NOTES ON DESIGN

- The quantity and position of the ISOPRO® IPH units are in accordance with the structural engineer's specifications.
- When using ISOPRO® IPH units, it must be ensured that the length and therefore also the load-bearing capacity of the linear connection is reduced by the proportion of the IPH units used.
- The steel rods of the ISOPRO® IPH units are anchored on both sides of the insulation joint. Therefore there is no connection reinforcement required.


UNIT STRUCTURE ISOPRO® IPH



IPH 1



IPH 2




IPH 3

DIMENSIONS AND ASSIGNMENT

ISOPRO®	IPH 1	IPH 2	IPH 3
Unit length [mm]		100	
Shear rods	2 x 1 Ø 8	–	2 x 1 Ø 8
Tension/pressure rods	–	1 Ø 10	1 Ø 10

DISTANCE BETWEEN EXPANSION JOINTS

By using ISOPRO® IPH units, a fixed point is created, resulting in increased constraints. The maximum permissible distance between expansion joints is therefore reduced to $e/2$ when ISOPRO® IPH units are used. Half of the maximum distance between expansion joints is always measured from the fixed point.







ISOPRO® IPE


UNITS FOR EARTHQUAKE LOADS

ISOPRO® IPE

- For cantilevered, continuous or supported slabs as a supplement to the ISOPRO® units
- For transferring horizontal forces parallel and perpendicular to the insulating joint and lifting (positive) moments in connection with an ISOPRO® IP/IPT unit
- Load-bearing capacities IPE 1 and IPE 2
- Clearly defined concrete covering, see design table
- Unit heights starting from $h_{\min} = 160$ mm
- Fire resistance class REI120 available

TYPE DESIGNATION


IPE 2 h200 REI120




APPLICATION – UNIT ARRANGEMENT




This chapter provides planning aids and specific information about this product. In addition, the general information on materials, design, building physics, installation on site, etc. on pages 10 - 24 has also to be considered.




ISOPRO® IPE – Cantilevered balcony with lifting moments



ISOPRO® IPE – Supported balcony with high horizontal forces




ISOPRO® IPE – Installation cross-section of thermal insulation composite system




ISOPRO® IPE – Installation cross-section of two-leaf masonry

UNIT STRUCTURE



ISOPRO® IPE 1




ISOPRO® IPE 2

DIMENSIONS AND ASSIGNMENT

ISOPRO®	IPE 1	IPE 2
Unit length [mm]	100	
Shear rods	2 x 1 Ø 8	2 x 1 Ø 12
Tension rods	2 Ø 8	2 Ø 12

DESIGN TABLE



ISOPRO® IPE – Sign regulation

DESIGN VALUES OF ALLOWABLE HORIZONTAL FORCES H_{Rd} [kN]

ISOPRO®	IPE 1		IPE 2		
	Concrete quality	C 20/25	C 25/30	C 20/25	C 25/30
Horizontal load, parallel $H_{Rd,II}$ [kN]		± 13.3	± 15.4	± 29.9	± 34.7
Horizontal load, vertical $H_{Rd,\perp}$ [kN] for $M_{Rd} = 0$		± 40.6	± 40.6	± 97.2	± 97.2

DESIGN VALUES OF ALLOWABLE LIFTING MOMENTS m_{Rd} [kNm]


Unit height [mm] depending on c_v [mm]		ISOPRO®	
		IPE 1	IPE 2
35	50		
160	–	3.7	8.2
–	180	3.9	8.7
170	–	4.1	9.1
–	190	4.4	9.6
180	–	4.6	10.1
–	200	4.8	10.6
190	–	5.0	11.1
–	210	5.2	11.6
200	–	5.5	12.1
–	220	5.7	12.6
210	–	5.9	13.1
–	230	6.1	13.6
220	–	6.3	14.1
–	240	6.5	14.6
230	–	6.8	15.0
–	250	7.0	15.5
240	–	7.2	16.0
250		7.6	17.0

DESIGN – EXPANSION JOINTS

NOTES ON DESIGN

- Moments can only be transferred in connection with adjoining ISOPRO® IP or IPT units.
- To transfer the positive moments indicated in the table, the tension rods of the ISOPRO® IP or IPT units adjacent to the ISOPRO® unit IPE are activated as pressure rods. To ensure this, at least the following adjacent units are recommended:
When using IPE 1 at least ISOPRO® IP35, when using IPE 2 at least ISOPRO® IP55.
- For the design, either $H_{Rd\perp}$ or M_{Rd} can be applied. This means that either a tensile force or a moment can be transferred with the unit; not both at the same time.
- The quantity and position of the ISOPRO® IPE units are in accordance with the structural engineer's specifications.
- When using ISOPRO® IPE units, ensure that the load-bearing capacity of the linear connection is reduced by the proportion of the length of the IPE units in relation to the total connection length.
- The tension rods at the bottom are to be overlapped with rods of the same diameter. The shear rods are anchored and require no further connection reinforcement.


DISTANCE BETWEEN EXPANSION JOINTS



If the component dimensions exceed the maximum permissible distance between expansion joints, expansion joints must be arranged perpendicular to the insulation plane. The maximum permissible distance between expansion joints e is dependent on the maximum rod diameter

across the expansion joint and is thus type-dependent. The maximum permissible distance between expansion joints for the ISOPRO® units is specified in the respective individual sections.

By using ISOPRO® IPE units, a fixed point is created, resulting in increased constraints. The maximum permissible distance between expansion joints is therefore reduced to $e/2$ when ISOPRO® IPE units are used. Half of the maximum distance between expansion joints is always measured from the fixed point.



ISOPRO® IPTA


UNITS FOR PARAPETS AND BALUSTRADES

ISOPRO® IPTA

- For transferring normal forces, positive and negative moments and horizontal forces
- Unit length 350 mm
- Parapet/balustrade width 160 to 250 mm
- Concrete covering varies depending on parapet thickness – see unit structure
- Ceiling thickness ≥ 160 mm
- Insulation thickness 80 mm
- Fire resistance class R90 available

TYPE DESIGNATION


IPTA b200 R90




APPLICATION – UNIT ARRANGEMENT




This chapter provides planning aids and specific information about this product. In addition, the general information on materials, design, building physics, installation on site, etc. on pages 10 - 24 has also to be considered.




ISOPRO® IPTA – View of parapet connected to the horizontal face



ISOPRO® IPTA – View of balustrade connected to the horizontal face




ISOPRO® IPTA – Installation cross-section of parapet




ISOPRO® IPTA – Installation cross-section of balustrade connected to the horizontal face

UNIT STRUCTURE



SIGN REGULATION/STATIC SYSTEM



DESIGN

DESIGN TABLE

ISOPRO®		IPTA b < 200 mm		IPTA b ≥ 200 mm	
Concrete quality		C20/25	≥ C25/30	C20/25	≥ C25/30
Moment M_{Rd} [kNm]	$N_{Ed} = 0$ kN	± 2,1	± 2,4	± 3,0	± 3,5
	$N_{Ed} > 0$ kN	$\pm(2,1 - N_{Ed}/2 \cdot 0,092)$	$\pm(2,4 - N_{Ed}/2 \cdot 0,092)$	$\pm(3,0 - N_{Ed}/2 \cdot 0,132)$	$\pm(3,5 - N_{Ed}/2 \cdot 0,132)$
Normal force N_{Rd} [kN]	$M_{Ed} = 0$ kNm	45,0	53,0	45,0	53,0
	$M_{Ed} \neq 0$ kNm	$45,0 - M_{Ed} /0,092 \cdot 2$	$53,0 - M_{Ed} /0,092 \cdot 2$	$45,0 - M_{Ed} /0,132 \cdot 2$	$53,0 - M_{Ed} /0,132 \cdot 2$
Horizontal force V_{Rd} [kN]		± 12,0	± 12,0	± 12,0	± 12,0

* As normal force only pressure can be transferred (no tensile force)

CONCRETE COVERING

Parapet/balustrade width b [mm]	Concrete covering c_v [mm]
150	25
160	30
170	35
180	40
190	45
200	30
210	35
220	40
230	45
240	50
250	55


ASSIGNMENT AND DIMENSIONS

ISOPRO®	IPTA
Unit length [mm]	350
Parapet/balustrade width b [mm]	160–250
Tension/pressure rods	3 Ø 8
Horizontal force rods	2 x 2 Ø 6

MAXIMUM PERMISSIBLE DISTANCE BETWEEN EXPANSION JOINTS

ISOPRO®	IPTA
Distance between joints e [m]	13.0

EDGES OF CEILINGS



The following distances must be maintained around the edges of ceilings or balustrades and around expansion joints

- Distance from the edge is not required around balustrades.
- A 50 mm distance from the edge must be maintained around ceilings.

Our Applications Technology department would be pleased to assist in finding further solutions.


Phone: +49 (0) 7742 9215-300

Fax: +49 (0) 7742 9215-319

E-mail: technik@h-bau.de

SUPPLEMENTARY REINFORCEMENT


ISOPRO® IPTA



- Item 1a connection reinforcement for the ISOPRO® unit in the balustrade – see table
- Item 1b connection reinforcement for the ISOPRO® unit in the ceiling – see table
- Item 2 spacing bar 2 x 2 Ø 8 on balustrade and ceiling side
- Item 3 structural edging in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications
- Item 4 structural edging at the free balcony edge in accordance with DIN EN 1992-1-1 min. Ø 6/250 respectively in accordance with the structural engineer's specifications (not shown here)
- Item 5 supplementary reinforcement for the ISOPRO® unit in the balustrade – see table
- Item 6 connecting stirrup supplied ex works 3 Ø 8
- For ISOPRO®IPTA units with parapet/balustrade widths of 150, 160 and 200 mm, the supplementary reinforcement of the parapet/balustrade must be arranged within the unit reinforcement, as this has a concrete covering of $c_v < 35$ mm.

CONNECTION AND SUPPLEMENTARY REINFORCEMENT

ISOPRO®	Supp. reinforcement, item 5	Connection reinforcement for balustrade Item 1a	Connection reinforcement for ceiling Item 1b
$A_{s,erf}$ [cm ²]	0.3	2 x 1.51	1.51
Suggestion	Ø 6/250	2 x 3 Ø 8	3 Ø 8



ISOPRO® IPTF


UNITS FOR BALUSTRADES CONNECTED TO THE VER- TICAL FACE

ISOPRO® IPTF

- For transferring positive shearing forces, positive and negative moments and horizontal forces
- Unit length 350 mm
- Unit heights 160 to 250 mm
- Concrete covering depending on the unit height – see unit structure
- Balustrade width ≥ 150 mm
- Insulation thickness 80 mm – 60 mm possible as an option
- Fire resistance class R90 available

TYPE DESIGNATION


IPTF h200 R90




APPLICATION – PRODUCT DETAILS




This chapter provides planning aids and specific information about this product. In addition, the general information on materials, design, building physics, installation on site, etc. on pages 10 - 24 has also to be considered.



ISOPRO® IPTF – Plan view of balustrade connected to the vertical face



ISOPRO® IPTF – Installation cross-section of a balustrade connected to the vertical face with a thermal insulation composite system




ISOPRO® IPTF – Installation cross-section of a balustrade connected to the vertical face with thermally insulating masonry

DESIGN TABLE FOR CONCRETE \geq C20/25


ISOPRO®	IPTF $h < 200$ mm	IPTF $h \geq 200$ mm
Moment M_{Rd} [kNm]	$\pm 2,1$	$\pm 3,0$
Horizontal force H_{Rd} [kN]	$\pm 3,5$	$\pm 3,5$
Shearing force V_{Rd} [kN]	12,0	12,0

SIGN REGULATION/STATIC SYSTEM



UNIT STRUCTURE - EXPANSION JOINTS

ISOPRO® IPTF



ASSIGNMENT AND DIMENSIONS

ISOPRO®	IPTF
Unit length [mm]	350
Unit height h [mm]	160–250
Tension/pressure rods	3 Ø 6
Horizontal force rods	2 Ø 6


MAX. PERMISSIBLE DISTANCE BTW. EXP. JOINTS

ISOPRO®	IPTF
Distance between joints e [m]	13.0

CONCRETE COVERING

Unit height h [mm]	Concrete covering at the bottom cv [mm]
160	30
170	40
180	50
190	60
200	70
210	80
220	90
230	100
240	110
250	120

DISTANCE FROM THE EDGE:



The following distances must be maintained around the edges of ceilings or balustrades and around expansion joints

- Distance from the edge is not required around balustrades.
- A 50 mm distance from the edge must be maintained around ceilings.

Our Applications Technology department would be pleased to assist in finding further solutions.


Phone: +49 (0) 7742 9215-300

Fax: +49 (0) 7742 9215-319

E-mail: technik@h-bau.de

SUPPLEMENTARY REINFORCEMENT

ISOPRO® IPTF



- Item 1a connection reinforcement for the ISOPRO® unit in the balustrade – see table
- Item 1b connection reinforcement for the ISOPRO® unit in the ceiling – see table
- Item 2 spacing bar 2 x 2 Ø 8 on balustrade and ceiling side
- Item 4 connecting bars for the ISOPRO® unit in the balustrade – see table
- Item 5 supplementary reinforcement for the ISOPRO® unit
- Item 6 connecting bars supplied ex works 3 Ø 8

CONNECTION AND SUPPLEMENTARY REINFORCEMENT

ISOPRO®	Supp. reinforcement, item 5	Connection reinforcement for bar, item 4	Connection reinforcement for balustrade, item 1a	Connection reinforcement for ceiling, item 1b
$a_{s,erf}$ [cm ² /m]	1.13	1.51	2 x 1.51	1.51
Suggestion	Ø 6/250	3 Ø 8	2 x 3 Ø 8	3 Ø 8

NOTES

- For the reinforcement and selection of distances between the ISOPRO® IPTF units, note the ability for concreting.
- For ISOPRO® IPTF units with parapet/balustrade widths of 130 to 160 mm, item 4 can be omitted, as this is covered by item 6.



ISOPRO® IPO


UNITS FOR CORBELS

ISOPRO® IPO

- For corbels that are used to support masonry or prefabricated units
- For transferring positive shearing forces, the resulting negative moments and horizontal forces
- Unit length 350 mm
- Unit heights 180 to 250 mm
- Concrete covering varies depending on the unit height – see unit structure
- Corbel width ≥ 160 mm
- Insulation thickness 80 mm – 60 mm possible as an option
- Fire resistance class REI120 available

TYPE DESIGNATION


IPO h200 REI120




APPLICATION – PRODUCT DETAILS




This chapter provides planning aids and specific information about this product. In addition, the general information on materials, design, building physics, installation on site, etc. on pages 10 - 24 has also to be considered.



ISOPRO® IPO – Plan view of corbel




ISOPRO® IPO – Corbel with facing masonry



ISOPRO® IPO – Corbel as support for a prefabricated component, support with centring bearing

SIGN REGULATION/STATIC SYSTEM



DESIGN - UNIT STRUCTURE

DESIGN TABLE FOR CONCRETE \geq C20/25

ISOPRO®		IPO					
Concrete quality		C20/25			\geq C25/30		
Load transfer point x [mm]		60 - 90	100	110	60 - 90	100	110
lateral force V_{Rd} [kN] depending on the unit height h [mm]	180	23.3	23.3	17.3	26.9	25.9	17.3
	200	23.3	23.3	20.3	26.9	26.9	20.3
	220	23.3	23.3	23.3	26.9	26.9	23.3
	240	23.3	23.3	23.1	26.9	26.9	23.1
	250	23.3	23.3	22.9	26.9	26.9	22.9
Horizontal force H_{Rd} [kN]		± 2.5			± 2.5		


ASSIGNMENT AND DIMENSIONS

ISOPRO®	IPO
Unit length [mm]	350
Unit height h [mm]	180–250
Tension rods	2 \varnothing 8
Shear rods	3 \varnothing 10
Compression bearings	2

CONCRETE COVERING

Unit height h [mm]	Concrete covering at top c_v [mm]	Concrete covering at bottom c_{v_u} [mm]
180	30	30
190	40	30
200	30	30
210	40	30
220	30	30
230	40	30
240	40	40
250	50	40

UNIT STRUCTURE




EXPANSION JOINTS - SUPP. REINFORCEMENT

MAXIMUM PERMISSIBLE DISTANCE BETWEEN EXPANSION JOINTS

ISOPRO®	IPTF
Distance between joints e [m]	13.0


DISTANCE FROM THE EDGE



The following distances must be maintained around the edges of ceilings or balustrades and around expansion joints:

- Distance from the edge is not required around balustrades.
- A 50 mm distance from the edge must be maintained around ceilings.

SUPPLEMENTARY REINFORCEMENT



- Item 1 connection reinforcement for the ISOPRO® unit 3 Ø 8
- Item 2 spacing bar 2 Ø 8 on the ceiling and at least 4 Ø 8 in the corbel
- Item 3 structural edging in accordance with DIN EN 1992-1-1 min. Ø 6/250
- Item 4 closed bar in the corbel in accordance with the structural engineer's specifications



ISOPRO® IPTS


UNITS FOR CANTILEVERED JOISTS

ISOPRO® IPTS

- For transferring negative moments and positive shearing forces
- Load-bearing capacities IPTS 1 to IPTS 4
- Unit widths 220 to 300 mm
- Unit heights 300 to 600 mm
- Concrete covering c_v 50 mm at the top, bottom and side
- Fire resistance class R90 available

TYPE DESIGNATION


IPTS 2 b/h = 220/400 R90




APPLICATION – PRODUCT DETAILS




This chapter provides planning aids and specific information about this product. In addition, the general information on materials, design, building physics, installation on site, etc. on pages 10 - 24 has also to be considered.




ISOPRO® IPTS – Balcony structure with prefabricated slabs joined by a non-static connection, and load-carrying joists



ISOPRO® IPTS – Balcony structure with joists connected to the balcony slab monolithically



ISOPRO® IPTS – Installation cross-section with prefabricated slabs



ISOPRO® IPTS – Installation cross-section with joists connected to the balcony slab monolithically

DESIGN TABLE

DESIGN VALUES OF ALLOWABLE MOMENTS M_{Rd} [kNm]

Unit height [mm]/ Concrete quality	ISOPRO®							
	IPTS 1		IPTS 2		IPTS 3		IPTS 4	
	C20/25	≥ C25/30	C20/25	≥ C25/30	C20/25	≥ C25/30	C20/25	≥ C25/30
300	16.5	19.4	23.5	26.4	31.6	36.1	40.6	47.7
350	20.8	24.5	29.8	33.5	40.2	45.9	51.8	60.8
400	25.2	29.6	36.0	40.5	48.7	55.7	63.0	73.9
600	42.7	50.1	61.2	68.8	82.9	94.7	107.6	126.4


DESIGN VALUES OF ALLOWABLE SHEARING FORCES V_{Rd} [kN]

ISOPRO®	IPTS 1		IPTS 2		IPTS 3		IPTS 4	
Concrete quality	C20/25	≥ C25/30	C20/25	≥ C25/30	C20/25	≥ C25/30	C20/25	≥ C25/30
Shearing force V_{Rd} [kN]	26.3	30.9	41.1	48.3	59.2	69.5	80.6	94.6


DIMENSIONS AND ASSIGNMENT

ISOPRO®	IPTS 1	IPTS 2	IPTS 3	IPTS 4
Unit width [mm]	220–300			
Unit height [mm]	300–600			
Tension rods	3 Ø 10	3 Ø 12	3 Ø 14	3 Ø 16
Shear rods	2 Ø 8	2 Ø 10	2 Ø 12	2 Ø 14
Pressure rods	3 Ø 12	3 Ø 14	3 Ø 14	3 Ø 20

UNIT STRUCTURE



ISOPRO® IPTS



ISOPRO® IPTS – Version with fireproof panels – R90

ISOPRO®	IPTS 1	IPTS 2	IPTS 3	IPTS 4
Length tension rod* X_1	740	860	860	860
Length Shear rod X_2	420	530	630	740
Length pressure rod X_3	580	650	785	955


* The anchoring length of the tension rods is designed for bonding area 1, "good bonding conditions". On request, the anchoring length of the tension rods can also be designed for bonding area 2, "moderate bonding conditions".

EXPANSION JOINTS – SITE REINFORCEMENT

MAXIMUM PERMISSIBLE DISTANCE BETWEEN EXPANSION JOINTS

ISOPRO®	IPTS 1	IPTS 2	IPTS 3	IPTS 4
Distance between joints e [m]	11.3	10.1	9.2	8.0

ISOPRO® IPTS



- Item 1 connection reinforcement for the ISOPRO® unit – see table
- Item 2 structural edging in accordance with DIN EN 1992-1-1 min. $\varnothing 6/250$
- Item 3 supplementary reinforcement for the ISOPRO® unit – see table

CONNECTION REINFORCEMENT ITEM 1

ISOPRO®	IPTS 1	IPTS 2	IPTS 3	IPTS 4
$a_{s,erf}$ [cm ² /m]	2.35	3.39	4.61	6.03
Suggestion	3 \varnothing 10	3 \varnothing 12	3 \varnothing 14	3 \varnothing 16

SUPPLEMENTARY REINFORCEMENT ITEM 3

ISOPRO®	IPTS 1	IPTS 2	IPTS 3	IPTS 4
$a_{s,erf}$ [cm ² /m]	0.71	1.11	1.59	2.17
Suggestion	2 \varnothing 8	2 \varnothing 10	2 \varnothing 10	2 \varnothing 12

Our Applications Technology department would be pleased to assist in finding further solutions.

Phone: +49 (0) 7742 9215-300

Fax: +49 (0) 7742 9215-319

E-mail: technik@h-bau.de



ISOPRO® IPTW


UNITS FOR CANTILEVERED RC WALLS

ISOPRO® IPTW

- For transferring negative moments, positive shearing forces and horizontal forces
- Load-bearing capacities IPTW 1 to IPTW 4
- Unit widths 150 to 250 mm
- Unit heights 1.500 to 3.500 mm
- Concrete covering cv 50 mm at the top and bottom and cv 25 to cv 50 at the side, depending on the unit width
- Fire resistance class R90 available
- Delivery of the units in at least three sub-units – bottom section with pressure and shear rods, intermediate section and top section with tension rods. For large unit heights, additional intermediate sections are added.

TYPE DESIGNATION


IPTW 2 b/h = 220/2.000 R90




APPLICATION – UNIT ARRANGEMENT



This chapter provides planning aids and specific information about this product. In addition, the general information on materials, design, building physics, installation on site, etc. on pages 10 - 24 has also to be considered.



ISOPRO® IPTW – Arrangement of units in the floor plan in combination with a balcony slab



ISOPRO® IPTW – Installation cross-section with wall slab connected to the balcony slab monolithically

DESIGN TABLE

DESIGN VALUES OF ALLOWABLE MOMENTS M_{Rd} [kNm]

Unit height [mm]/ Concrete quality	ISOPRO®							
	IPTW 1		IPTW 2		IPTW 3		IPTW 4	
	C20/25	≥ C25/30	C20/25	≥ C25/30	C20/25	≥ C25/30	C20/25	≥ C25/30
≥ 1.500	64.7		124.5	115.3		178.7		178.7
≥ 1.750	76.6		147.8	136.8		212.7		212.7
≥ 2.000	88.4		171.0	158.4		246.8		246.8
≥ 2.250	100.3		194.2	179.9		280.8		280.8
≥ 2.500	112.1		217.4	201.4		314.8		314.8
≥ 2.750	124.0		240.7	222.9		348.8		348.8
≥ 3.000	135.8		263.9	244.4		382.9		382.9

DESIGN VALUES OF ALLOWABLE SHEARING FORCES V_{Rd} [kN] AND HORIZONTAL FORCES H_{Rd} [kN]

ISOPRO®	IPTW 1		IPTW 2		IPTW 3		IPTW 4	
Concrete quality	C20/25	≥ C25/30	C20/25	≥ C25/30	C20/25	≥ C25/30	C20/25	≥ C25/30
Shearing force V_{Rd} [kN]	44.4	52.1	79.0	92.7	131.6	154.5	205.6	241.3
Horizontal force H_{Rd} [kN]	± 14.8	± 17.4	± 14.8	± 17.4	± 14.8	± 17.4	± 14.8	± 17.4

DIMENSIONS AND ASSIGNMENT

ISOPRO®	IPTW 1		IPTW 2		IPTW 3		IPTW 4	
Unit width [mm]	150–250							
Unit height [mm]	1500–3500							
Tension rods	2 Ø 10		4 Ø 10		4 Ø 12		4 Ø 12	
Shear rods	6 Ø 6		8 Ø 6		10 Ø 8		10 Ø 10	
Horizontal rods	2 x 2 Ø 6							
Pressure rods	4 Ø 10		4 Ø 10		6 Ø 12		6 Ø 14	

NOTES ON DESIGN

- The anchoring length of the tension rods is designed for connection area 2, "moderate connection conditions".
- Moments from wind loads perpendicular to the wall slab cannot be borne by the ISOPRO® IPTW unit. These loads are transferred through the stiffening effect of the monolithically connected balcony slabs. If this is not possible, the ISOPRO® IPTW unit can be supplemented with an ISOPRO® IPTD unit. This then replaces the intermediate component.

Our Applications Technology department would be pleased to assist in finding further solutions.
 Phone: +49 (0) 7742 9215-300
 Fax: +49 (0) 7742 9215-319
 E-mail: technik@h-bau.de

DISTANCE BETWEEN EXPANSION JOINTS

DISTANCE BETWEEN EXPANSION JOINTS

If the component dimensions exceeds the maximum permissible distance between expansion joints, expansion joints must be arranged perpendicular to the insulation plane. The maximum permissible distance between expansion joints e is dependent on the maximum rod diameter guided across the expansion joint and is thus type-dependent.


Fixed points, such as support above a corner, result in increased constraints. As a result, the maximum permissible distance between expansion joints must be reduced to $e/2$. Half of the maximum distance between expansion joints is always measured from the fixed point.

If walls joined using ISOPRO® IPTW have a rigid connection with long balcony slabs, the maximum distances between expansion joints specified below shall apply.


MAXIMUM PERMISSIBLE DISTANCE BETWEEN EXPANSION JOINTS

ISOPRO®	IPTW 1/IPTW 2	IPTW 3	IPTW 4
Distance between joints e [m]	13.0	11.3	10.1

UNIT STRUCTURE ISOPRO® IPTW



ISOPRO® IPTW





ISOPRO® IPTW – Version with fireproof panels – R90

ISOPRO®	IPTW 1	IPTW 2	IPTW 3	IPTW 4
Length tension rod X_1	740	740	860	860
Length shear rod X_2	310/370	420	420	530
Length horizontal shear rod	450	450	450	450
Length pressure rod X_3	480	480	570	650

SUPPLEMENTARY REINFORCEMENT

ISOPRO® IPTW



- Item 1 connection reinforcement for the ISOPRO® unit – see table
- Item 2 spacing bar 2 Ø 8
- Item 3 structural edging in accordance with DIN EN 1992-1-1 min. Ø 6/250
- Item 5 supplementary reinforcement for the ISOPRO® unit, anchored with stirrups – see table
- During concreting, even filling and compression on both sides must be ensured, as well as secure positioning.

CONNECTION REINFORCEMENT ITEM 1

ISOPRO®	IPTW 1	IPTW 2	IPTW 3	IPTW 4
$A_{s,erf}$ [cm ²]	1.57	3.14	4.5	4.5
Suggestion	2 Ø 10	4 Ø 10	4 Ø 12	4 Ø 12

SUPPLEMENTARY REINFORCEMENT ITEM 5

ISOPRO®	IPTW 1	IPTW 2	IPTW 3	IPTW 4
$A_{s,erf}$ [cm ²]	1.19	2.13	3.55	5.54
Suggestion	2 x 2 Ø 8	2 x 2 Ø 10	2 x 2 Ø 12	2 x 2 Ø 14





ISOPRO® Z-ISO


UNITS AS
INTERMEDIATE
INSULATION

ISOPRO® Z-ISO


- No structural function
- Length 1000 mm
- Unit heights starting from 160 mm
- Short units and units up to a height of 280 mm available on request.
- Fire resistance classes FP 1 with fireproof panels

TYPE DESIGNATION


Z-ISO h200 FP1




APPLICATION – UNIT ARRANGEMENT




ISOPRO® Z-ISO – Balcony as prefabricated component with transport anchor – the Z-ISO units are added on site



ISOPRO® Z-ISO – Balcony on supports – Z-ISO units in the drainage recess area




ISOPRO® Z-ISO – Loggia with support at specific points with IPQS/IPQZ




ISOPRO® Z-ISO – Use of parapet units at specific points ISOPRO® IPTA


UNIT STRUCTURE




ISOPRO® Z-ISO – Product view



ISOPRO® Z-ISO – product cross-section



ISOPRO® Z-ISO FP1 – Product view with fireproof panels at the top and bottom



ISOPRO® Z-ISO FP1 – Product cross-section

A FORWARD CONSTRUCTING SERVICE: WE ARE ALWAYS THERE FOR YOU.


You can rely on our excellent service: We accompany you through every phase of the project – either over the phone, online or in person, directly at your site. As a true partner, we place special value on offering our customers added value – take a look at our comprehensive range of services and see for yourself.



READY TO GO: OUR TENDER DOCUMENT TEMPLATES.

Our tender document templates can be quickly and easily embedded in your tender program, e.g. with the tender managers at

www.ausschreiben.de or
www.heinze.de.



EVERYTHING ONLINE: OUR DOWNLOAD AREA.

You can download all brochures, test reports, approvals, our current price list and much more from our website.



FOR PLANNING AND APPLICATION: OUR VIDEOS AND SOFTWARE.

In addition to our installation and reference films, we also provide you with various software solutions, such as calculation programs, free of charge on our website.



HOTLINES

Personalised support when planning and executing projects:

Answers to any questions you have about delivery times, shipping, sales prices and the entire process of fulfilling your orders:

APPLICATION TECHNOLOGY

Hotline: +49 (0) 7742 9215-300
E-mail: technik@h-bau.de


SALES (GERMANY)

Hotline: +49 (0) 7742 9215-200
E-mail: vertrieb@h-bau.de



**TAILOR-MADE:
OUR SPECIAL CONSTRUCTIONS.**

Unable to find what you're looking for in our wide range of products and services? Our engineers and applications engineers will develop individual product solutions on request to meet your needs.



**FROM PERSON TO PERSON:
OUR NETWORK OF CONSULTANTS.**

Get the answers to your technical questions face-to-face at your site: Our consultant engineers will be happy to come to your site.



**THE LATEST NEWS:
OUR NEWSLETTER.**

Subscribe to our newsletter and you will always be kept up-to-date: Find out more about our product innovations, trade shows and current trends in the sector.

Answers to any questions you have about delivery times, shipping, sales prices and the entire process of fulfilling your orders at an international level:

SALES (INTERNATIONAL)

Hotline: +49 (0) 7742 9215-250
E-mail: export@h-bau.de

We will be happy to send you our technical brochures and planning documents:

HEAD OFFICE

Hotline: +49 (0) 7742 9215-0
E-mail: info@h-bau.de

FORWARD CONSTRUCTING CONTACTS: WE WILL BE WHEREVER YOU ARE.

Thanks to our global sales network, expert specialist advisors are available to you on a national level and on an international level. If there is no contact partner listed for your country, contact our Head Office in Klettgau – we will be happy to provide you with further assistance.



HEAD OFFICE

H-BAU TECHNIK GMBH

Am Güterbahnhof 20
79771 Klettgau, Germany
Phone: +49 (0) 7742 9215-0
Fax: +49 (0) 7742 9215-129
E-mail: info@h-bau.de
www.h-bau.com

PRODUCTION: NORTH-EAST

Brandenburger Allee 30
14641 Nauen OT Wachow, Germany
Phone: +49 (0) 33239 775-0
Fax: +49 (0) 33239 775-90
E-mail: info.berlin@h-bau.de

PRODUCTION: CHEMNITZ

Beyerstraße 21
09113 Chemnitz, Germany
Phone: +49 (0) 371 40041-0
Fax: +49 (0) 371 40041-99
E-mail: info.chemnitz@h-bau.de

JORDAHL H-BAU VERTRIEBS GMBH

Our products are sold in Germany exclusively through the following subsidiaries of JORDAHL H-BAU Vertriebs GmbH:

ESSEN

JORDAHL H-BAU Vertriebs GmbH
Carnaperhof 7
45329 Essen, Germany
Phone: +49 (0) 201 289660
Fax: +49 (0) 201 2896620
E-mail: essen@jordahl-hbau.de

NUREMBERG

JORDAHL H-BAU Vertriebs GmbH
Lechstraße 21
90451 Nuremberg, Germany
Phone: +49 (0) 911 6412980
Fax: +49 (0) 911 6496099
E-mail: nuernberg@jordahl-hbau.de

MANNHEIM

JORDAHL H-BAU Vertriebs GmbH
Markircher Straße 14
68229 Mannheim, Germany
Phone: +49 (0) 621 4840340
Fax: +49 (0) 621 4840344
E-mail: mannheim@jordahl-hbau.de

You are also welcome to contact our Head Office in Klettgau directly.

GLOBAL PARTNERS

SWITZERLAND

JORDAHL H-BAU AG
 Wasterkingergweg 2
 CH-8193 Eglisau
 Phone: +41 44 8071717
 Fax: +41 44 8071718
 Email: info@jordahl-hbau.ch
 www.jordahl-hbau.ch

AUSTRIA

JORDAHL H-BAU
 Österreich GmbH
 Straubingstrasse 19
 4030 Linz, Austria
 Phone: +43 (0) 732 321900
 Fax: +43 (0) 732 321900-99
 E-mail: office@jordahl-hbau.at
 www.jordahl-hbau.at

FRANCE

JORDAHL H-BAU France SARL
 Siège
 7 rue des Vallières Sud
 25220 Chalezeule, France
 Phone: +33 (0) 381 250465
 Fax: +33 (0) 381 250796
 E-mail: info@jordahl-hbau.fr
 www.jordahl-hbau.fr

NETHERLANDS

JORDAHL H-BAU
 Bezoekadres
 Jan Tinbergenstraat 221
 7559 SP Hengelo, Netherlands
 Phone: +31 (0) 74 2505737
 Fax: +31 (0) 74 2503321
 E-mail: info@jordahl-hbau.nl
 www.jordahl-hbau.nl

DENMARK

Jordahl & Pfeifer Byggeteknik A/S
 Risgårdevej 66
 9640 Farsø, Denmark
 Phone: +45 (0) 98 631900
 Phone: +45 (0) 98 631939
 E-mail: info@jordahl-pfeifer.dk
 www.jordahl-pfeifer.dk

HUNGARY

PFEIFER Garant Kft.
 Gyömrői út 128
 1103 Budapest, Hungary
 Phone: +36 (0) 1 2601014
 Fax: +36 (0) 1 2620927
 E-mail: info@pfeifer-garant.hu
 www.pfeifer-garant.hu

UNITED KINGDOM

J&P Building Systems Ltd.
 Unit 5
 Thame Forty
 Jane Morbey Road
 THAME, OXON OX9 3RR, UK
 Phone: +44 (0) 1844 215200
 Fax: +44 (0) 1844 263257
 enquiries@jandpbuildingsystems.com
 www.jp-uk.com

UKRAINE

JORDAHL & PFEIFER
 Technika Budowlana
 ul. Pawlyka 17a
 76-018 Ivano-Frankivsk, Ukraine
 Phone Reg. East: +380 (0) 67442 8578
 Phone Reg. West: +380 (0) 67442 8579
 E-mail: info@j-p.com.ua

CZECH REPUBLIC

JORDAHL & PFEIFER
 Stavební technika s.r.o.
 Bavorská 856/14
 15500 Prague 5, Czech Republic
 Phone: +420 (0) 272 700701
 Fax: +420 (0) 272 700704
 E-mail: info@jpcz.cz
 www.jpcz.cz

SPAIN

PFEIFER Cables y Equipos de Elevación, S.L.
 Avda.de Los Pirineos, 25 – Nave 20
 San Sebastian de los Reyes
 28700 Madrid, Spain
 Phone: +34 (0) 91 659 3185
 Fax: +34 (0) 91 659 3139
 E-mail: p-es@pfeifer.de
 www.pfeifer.es

SINGAPORE

J&P Building Systems Pte Ltd.
 No. 48 Toh Guan Road East
 #08-104 Enterprise Hub
 SINGAPORE 608586
 Phone: +65 (0) 6569 6131
 Fax: +65 (0) 6569 5286
 E-mail: info@jnp.com.sg
 www.jnp.com.sg

ROMANIA

S.C. JORDAHL & PFEIFER TEHNICĂ DE
 ANCORARE S.R.L
 Str. Malului Nr. 7, et.1
 550197 Sibiu jud. Sibiu, Romania
 Phone: +40 (0) 269 246098
 Fax: +40 (0) 269 246099
 E-mail: info@jordahl-pfeifer.ro
 www.jordahl-pfeifer.ro

POLAND

JORDAHL & PFEIFER TECHNIKA
 BUDOWLANA SP. Z O. O.
 ul. Wroclawska 68
 55-330 Krępiec k/Wrocławia, Poland
 Phone: +48 (0) 71 3968264
 Fax: +48 (0) 71 3968105
 E-mail: biuro@jordahl-pfeifer.pl
 www.j-p.pl

Disclaimer

1. This work and all parts thereof are protected by copyright law. Use of this work is not be permitted without the agreement of H-BAU Technik GmbH.
2. All texts and diagrams in this printed product have been developed and compiled with the utmost care and are designed to provide preliminary information. Nevertheless, errors cannot be completely excluded. The publisher shall assume no liability, irrespective of the legal grounds for this. Previous documents shall become invalid with the issue of this document.

Forward constructing.

H-BAU TECHNIK GMBH

Am Güterbahnhof 20

79771 Klettgau, Germany

Phone: +49 (0) 7742 9215-0

Fax: +49 (0) 7742 9215-129

E-mail: info@h-bau.de